
Operating instructions

51167690

08.12









Declaration of Conformity



Jungheinrich AG, Am Stadtrand 35, D-22047 Hamburg Manufacturer or agent acting in the European Union

Туре	Option	Serial no.	Year of manufacture
DFG 540 DFG 545 DFG 550 TFG 540 TFG 545 TFG 550			

Additional information

On behalf of

Date

EU Conformity Declaration

The undersigned hereby declare that the powered industrial truck described below in detail complies with the European Directives 2006/42/EC (Machinery Directive) and 2004/108/EEC (Electromagnetic Compatibility - EMC) including amendments as well as the legislative decree to incorporate the directives in national law. The signatories are in each case individually authorized to compile the technical documents.

Foreword

Notes on the operating instructions

The present ORIGINAL OPERATING INSTRUCTIONS are designed to provide sufficient instruction for the safe operation of the industrial truck. The information is provided clearly and concisely. The chapters are arranged by letter and the pages are numbered continuously.

The operator manual details different industrial truck models. When operating and servicing the industrial truck, make sure that the particular section applies to your truck model.

Our trucks are subject to ongoing development. Jungheinrich reserves the right to alter the design, equipment and technical features of the system. No guarantee of particular features of the truck should therefore be assumed from the present operating instructions.

Safety notices and text mark-ups

Safety instructions and important explanations are indicated by the following graphics:

↑ DANGER!

Indicates an extremely hazardous situation. Failure to comply with this instruction will result in severe irreparable injury and even death.

MARNING!

Indicates an extremely hazardous situation. Failure to comply with this instruction may result in severe irreparable injury and even death.

⚠ CAUTION!

Indicates a hazardous situation. Failure to comply with this instruction may result in slight to medium injury.

NOTE

Indicates a material hazard. Failure to comply with this instruction may result in material damage.

- Used before notices and explanations.
 - Indicates standard equipmentIndicates optional equipment

Copyright

Copyright of these operating instructions remains with JUNGHEINRICH AG.

Jungheinrich Aktiengesellschaft

Am Stadtrand 35 22047 Hamburg - Germany

Tel: +49 (0) 40/6948-0

www.jungheinrich.com

Contents

Α	Correct Use and Application	11
1 2 3 4 5	General Correct application Approved application conditions Proprietor responsibilities Adding attachments and/or accessories	11 11 12 13
В	Truck Description	15
1 1.1 2.1 2.2 3.1 3.2 3.4 3.5 3.6 3.7 3.8 4.1 4.2 4.3 5	Application Truck models and rated capacity Assemblies and Functional Description Assembly Overview Functional Description Technical Specifications Performance data Dimensions Weights Mast versions Tyre type Engine Data EN norms Conditions of use Electrical requirements Identification points and data plates Data plate Truck capacity plate Attachment capacity plate Stability	15 16 16 17 19 19 21 23 24 26 27 28 29 30 32 33 34 34
С	Transport and Commissioning	35
1 2 2.1 2.2 2.3 3 4	Transport	35 35 35 36 37 38 39

D	Fuelling the Truck	41
1 1.1 1.2 2 2.1 2.2 3 3.1 3.2 4 4.1 4.2	General	41 43 44 45 46 49 50 50
E	Operation	51
1 2 2.1 2.2 2.3 3.1 3.2 3.3 3.4 3.5 4.1 4.2 4.3 4.4 4.5	Safety Regulations for the Operation of the Forklift Truck	51 53 55 57 58 59 60 61 65 66 68 71 72 73
4.9 4.10 4.11 4.12 4.13 4.14 5 6.1 6.2 6.3 6.5 6.6	Bianeing the forks Replacing the forks Lifting, transporting and depositing loads Operating the lift mechanism and integrated attachments Safety instructions for operating additional attachments Operating additional attachments for the SOLO-PILOT Fitting additional attachments Towing trailers Optional equipment Steel cab Sliding windows Panel door Backrest extension Heating Removable load backrest	74 77 78 79 81 86 89 91 93 95 96 96 97

6.7	Fire extinguisher	99
6.8	Rockinger coupling with hand lever or remote control	100
6.9	Camera system	101
6.10	Optional equipment for working in areas with heavy accumulation of dust	102
6.11	Tilt angle display	102
6.12	Speed reduction	103
6.13	Transmission block	103
6.14	Reversing Block	103
6.15	Direction switch mounted to the steering column	103
6.16	Temperature control system	104
6.17 7	Control layout with Cardan function	105
	Troubleshooting	106
7.1	Troubleshooting	106
7.2	Operating the truck without its own drive system	109
F	Industrial Truck Maintenance	113
1	Operational Safety and Environmental Protection	113
2	Maintenance Safety Regulations	114
3	Servicing and Inspection	119
4	Maintenance checklist	120
5	Lubricants and Lubrication Schedule	128
5.1	Handling consumables safely	128
5.2	Lubrication Schedule	130
5.3	Consumables	131
6	Maintenance and repairs	133
6.1	Preparing the truck for maintenance and repairs	133
6.2	Opening the engine cover	134
6.3		
	Checking the wheel attachments	135
6.4	Hydraulic system	136
6.5	Engine maintenance	139
6.6	Checking electrical fuses	151
6.7	Starter battery	156
6.8	Exhaust system	157
6.9	Seat belt maintenance	158
6.10	Transmission	158
6.11 6.12	BrakeRestoring the truck to service after maintenance and repairs	159 160
7	Decommissioning the industrial truck	161
, 7.1	Prior to decommissioning	162
7.1	During decommissioning	162
7.3	Restoring the truck to service after decommissioning	163
8	Safety tests to be performed at intervals and after unusual incidents	164
9	Final de-commissioning, disposal	165
10	Human vibration measurement	165
11	HUSS FS - MK Series Diesel Particle Filter Operating Instructions (O).	166
11.1	Important General Instructions	166
11.2	Important safety instructions	166

11.3	Functional Description	167
11.4	HUSS Control Operation	168
11.5	HUSS Control Operating Instructions	169
11.6	Regeneration	170
11.7	Maintenance	171

A Correct Use and Application

1 General

The industrial truck described in the present operating instructions is designed for lifting, lowering and transporting load units.

It must be used, operated and serviced in accordance with the present instructions. Any other type of use is beyond the scope of application and can result in damage to personnel, the industrial truck or property.

2 Correct application

NOTE

The maximum load and load distance are indicated on the load chart and must not be exceeded.

The load must rest on the load handler or be lifted by an attachment approved by the manufacturer.

The load must rest on the back of the fork carriage and centrally between the forks.

- Lifting and lowering loads.
- = Transporting lowered leads over short distances.
- Do not carry or lift passengers.
- Do push or pull load units.
- Occasional towing of trailer loads.
- When towing trailer loads the load must be secured on the trailer.
- The permissible trailer load must not be exceeded.

3 Approved application conditions

⚠ DANGER!

Do not exceed the permissible surface and spot load limits on the travel routes. At blind spots get a second person to assist.

The driver must ensure that the loading dock / ramp cannot move or come loose during loading / unloading.

- = Permissible temperature lange 20 cial environments.
- Operation only on secure, level surfaces with sufficient capacity.
- Operation only on routes that are visible and approved by the proprietor.
- Negotiating inclines up to a maximum of 15 %.
- Do not negotiate inclines crosswise or at an angle. Transporting loads downhill.
- Operation in partially public traffic.

↑ WARNING!

Extreme conditions

- ▶ Special equipment and authorisation are required if the truck is to be constantly used in extreme conditions, especially in dusty or corrosive atmospheres.
- ▶ The truck is not authorised for use in areas at risk of explosion.
- ▶ In adverse weather conditions (thunder, lightning) the industrial truck must not be operated outside or in endangered areas.

4 Proprietor responsibilities

For the purposes of the present operating instructions the "proprietor" is defined as any natural or legal person who either uses the industrial truck himself, or on whose behalf it is used. In special cases (e.g. leasing or renting) the proprietor is considered the person who, in accordance with existing contractual agreements between the owner and user of the industrial truck, is charged with operational duties.

The proprietor must ensure that the industrial truck is used only for the purpose for which it is intended and that there is no danger to life and limb of the user and third parties. Furthermore, accident prevention regulations, safety regulations and operating, servicing and repair guidelines must be followed. The proprietor must ensure that all users have read and understood these operating instructions.

NOTE

Failure to comply with the operating instructions shall invalidate the warranty. The same applies if improper work is carried out on the truck by the customer or third parties without the permission of the manufacturer.

5 Adding attachments and/or accessories

Adding accessories

The mounting or installation of additional equipment which affects or enhances the performance of the forklift truck requires the written permission of the manufacturer. Local authority approval may also need to be obtained.

Local authority approval does not however constitute the manufacturer's approval.

B Truck Description

1 Application

The DFG / TFG 540 - 550 is a four-wheel IC motor sit-down forklift truck. The DFG series are diesel engine trucks, while the TFG series are fitted with a petrol engine for LPG operation.

The DFG / TFG 540 - 550 is a cantilever counterbalanced truck which can lift, transport and deposit loads using the load handler attached in front.

Closed bottom pallets can also be lifted.

The DFG / TFG 540 - 550 is equipped with a hydrodynamic drive. The left pedal is a combination of crawl speed and brake pedal, and activates the rapid lift function during slow travel. The middle pedal is a standard brake as well as emergency brake pedal.


1.1 Truck models and rated capacity

The rated capacity depends on the model. The rated capacity can be derived from the model description.

DFG540


DFG	Model name
5	Series
40	Rated capacity x 100 kg

The rated capacity does not generally match the permissible capacity. The capacity can be found on the load chart attached to the rack.



2 Assemblies and Functional Description

2.1 Assembly Overview



Item Description		Description	Item		Description
1	•	Overhead guard	8		Drive
2	•	Driver's seat Steering wheel	9	• •	Lifting device control Engine cover
4	•	Mast	11	•	Steer axle
5	•	Control / display unit	12	•	Trailer coupling
6	•	Fork carriage	13		Counterweight
7	•	Fork tines	14	•	LPG bottle (TFG only)
3	A -	- Standard aguinment	83 (- Ontional equipment
	■ = Standard equipment □ = Optional equipment			= Optional equipment	

2.2 Functional Description

Chassis

The chassis, in conjunction with the counterweight, forms the supporting base structure of the truck. It is used to support the main components.

The hydraulic oil reservoir is integrated on the right-hand side and the fuel tank for the DFG series is on the left side in the chassis.

Operator position and overhead guard

The overhead guard (1) comes in a range of models and protects the driver from falling objects and other external influences.

All the controls are ergonomically arranged. The steering column and driver's seat can be adjusted individually.

The controls and warnings on the display unit (5) enable the system to be monitored during operation, thereby ensuring a very high level of safety.

Steering

The steer cylinder of the hydrostatic steering is integrated in the steer axle (11) and is controlled by the power steering. The steer axle is fully floating in the chassis to ensure excellent grip even on non-level surfaces.

Wheels

All wheels are located within the truck geometry. A choice of pneumatic or superelastic tyres are available.

Engine

High performance, water-cooled diesel and LPG engines with long useful lives and low consumption and emission levels.

Electrical system

12 volt system with threephase alternator. A start block prevents malfunctions when the truck is powered up. For diesel engines, a rapid pre-heat system is installed; LPG motors have an electronic ignition system for rapid and trouble-free engine starting. The key switch is used to stop the engine.

Drive system

A power shift transmission with radiator and torque converter transfers the force to the drive axle (8).

The travel direction switch on the engine cover controls forward/reverse travel and the neutral position. This switch is used to select between the two travel stages for forward and reverse travel.

Brakes

The brake second actual to save fell brakes wheely deplications. Wheely deplications wheely deplications wheely deplications wheely deplications wheely deplications wheely deplication of the parking adjusted. The parking brake operates through mechanical actuation of the parking brake lever on the drum brake via Bowden cables.

Hydraulic system

A multi-pilot valve allows for sensitive operation of the functions via the controls. The flow rate of the gear pump is regulated by the engine speed.

Mast

Two or three-stage masts, optionally with free lift function; narrow mast sections ensure excellent visibility of the forks and attachments. Fork carriage and mast run on permanently lubricated and hence maintenance-free support rollers.

Attachments

The trucks can be optionally fitted with mechanical and hydraulic attachments.

3 Technical Specifications

All technical details refer to standard trucks. Values indicated with *) may vary, depending on the types of equipment used (e.g. mast, cabin, tyres etc.).

Technical data specified in accordance with VDI 2198. Technical modifications and additions reserved.

3.1 Performance data

DFG 540/545/550

3	Description	DFG 540	DFG 545	DFG 550	ř
Q	Capacity (where C = 500 mm) ¹⁾	4000	4500	5000	kg
С	Load centre distance	500	500	600	mm
); 	Travel speed* with / without load	24/24.5	23/23.5	22/22.5	km/h
8	Lift speed, with / without load	0.49/0.53	0.49/0.53	0.48/0.53	m/s
	Lowering speed with / without load	0.51/0.49	0.51/0.49	0.51/0.49	m/s
	Gradeability ²⁾ * with / without load	25/26	24/26	23/26	%
	Acceleration* with / without load to 15 m	5/4.5	5/4.5	5.1/4.5	s
	Available working pressure for attachments	160	160	160	bar
	Oil flow for attachments	30	30	30	l/min

¹⁾ for vertical mast.

²⁾ The values shown represent the maximum gradeability to overcome short differences in height and surface unevenness (surface edges). The truck must not operate on inclines of more than 15%.

TFG 540/545/550

	Description	TFG 540	TFG 545	TFG 550
Q	Capacity (where C = 500 mm) ¹⁾	4000	4500	5000
С	Load centre distance	500	500	600
	Travel speed* with / without load	24.4/25.8	23.8/25.8	22.3/25.8
	Lift speed, with / without load	0.49/0.53	0.48/0.53	0.48/0.53
	Lowering speed with / without load	0.51/0.49	0.51/0.49	0.51/0.49
	Gradeability ²⁾ * with / without load	25/26	24/26	23/26
	Acceleration* with / without load to 15 m	4.8/4.2	5/4.5	5.5/4.5
	Available working pressure for attachments	160	160	160
	Oil flow for attachments	30	30	30

¹⁾ for vertical mast.

²⁾ The values shown represent the maximum gradeability to overcome short differences in height and surface unevenness (surface edges). The truck must not operate on inclines of more than 15%.


3.2 Dimensions


DFG/TFG 540/545/550

3	Description	DFG / TFG				
		540	545	550		
a/2	Safety distance	100	100	100	mm	
h ₁	Mast height retracted*	2540	2540	2540	mm	
h ₂	Free lift*	150	150	150	mm	
h ₃	Lift*	3500	3500	3500	mm	
h ₄	Mast height extended*	4215	4215	4363	mm	
h ₆	Overhead guard height (cabin)*	2375	2375	2375	mm	
h ₇	Seat height*	1255	1255	1255	mm	
h ₁₀	Coupling height	535/700	535/700	535/700	mm	
α	Mast tilt, fwd.*	7	7	7	0	
ß	Mast tilt, back*	6	6	6	٥	
I ₁	Overall length *	4145	4145	4260	mm	
l ₂	Headlength*	2995	2995	3110	mm	
b ₁	Overall width*	1400/-	1450/-	1450/-	mm	
s/e/l	Fork dimensions*	50x125	50x150	60x150	mm	
a .	<u>.</u>	x1150	x1150	x1150		
m ₁	Ground clearance with load below mast*	190	190	190	mm	
m ₂	Ground clearance centre wheelbase*	230	230	230	mm	
	Fork carriage ISO 2328 class / type A, B	3 A	3 A	4 A		
b ₃	Fork carriage width*	1260	1260	1260	mm	
Ast	Working aisle width for pallets 800 x 1200 longit.	4619	4619	4769	mm	
Ast	Working aisle width for pallets 1000 x 1200 traverse	4419	4419	4569	mm	
Wa	Turning radius	2655	2655	2790	mm	
b ₁₃	Smallest turning radius	900	900	900	mm	
Х	Load distance*	564 ¹⁾	564 ¹⁾	579 ¹⁾	mm	
С	Load centre of gravity	500	500	600	mm	
у	Wheelbase	1985	1985	1985	mm	

^{*)} The data listed in the table corresponds to the standard version.

 $^{^{1)}}$ 573 mm with DZ mast; with integrated SS: x=596 mm (605 mm with DZ mast); with SS attachment: x=636 mm (645 mm with DZ mast)





3.3 Weights

All dimensions in kg.

DFG/TFG 540/545/550

	DFG/TFG 540	DFG/TFG 545	DFG/TFG 550
Tare weight*	6279	6669	7434
Axle load, w.o. load front/	2810/3469	2937/3732	2795/4639
Axle load, w. load front/ rear*	8954/1325	9869/1300	10762/1673

^{*)} The data listed in the table corresponds to the standard version.

3.4 Mast versions

→

All dimensions in mm

DFG/TFG 540/545

Mast table								
VDI3596 Description	Lift h ₃	Free lift h ₂	Retracted height h ₁	Extended height h ₄	Mast weight (kg)			
	2750 3000	150 150	2165 2290	3465 3715	1135 1170			
	3500	150	2540	4215	1240			
	4000	150	2790	4715	1310			
ZT	4500	150	3040	5215	1430			
	5000	150	3290	5715	1500			
	5500	150	3540	6215	1570			
	6000	150	3790	6715	1690			
	6500	150	4040	7215	1760			
	2775	1375	2140	3540	1070			
	3025	1500	2265	3790	1110			
ZZ	3525	2758	2515 2765	4798	1188			
	4525	2250	3015	5290	1320			
	5025	2500	3265	5790	1440			
	5525	2750	3515	6290	1510			
	4150	1375	2140	4915	1500			
	4525	1500	2265	5290	1560			
DZ	5275	1750	2515	6040	1660			
	5650	1875	2640	6415	1720			
	6025	2000	2765	6790	1770			
ė.	6775	2250	3015	7540	1920			

Special trucks are not included in this overview.

DFG/TFG 550

Mast table					
VDI3596 Description	Lift h ₃	Free lift h ₂	Retracted height h ₁	Extended height h ₄	Mast weight (kg)
	2750	150	2165	3613	1200
	3000	150	2290	3863	1240
	3500	150	2540	4363	1310
	4000	150	2790	4863	1380
ZT	4500	150	3040	5363	1500
	5000	150	3290	5863	1570
	5500	150	3540	6363	1640
	6000	150	3790	6863	1760
	6500	150	4040	7363	1820
	2725	1225	2140	3640	1140
	2975	1350	2265	3890	1170
	3475	1600	2515	4390	1240
ZZ	3975	1850	2765	4890	1310
	4475	2100	3015	5390	1385
	4 <u>975</u> 5475	2350 2600	3265 3515	5890 6390	1500 1580
	5475	2600	3515	6390	1580
	4050	1225	2140	4965	1570
	4425	1350	2265	5340	1620
DZ	5175	1600	2515	6090	1730
DZ.	5550	1725	2640	6465	1780
	5925	1850	2765	6840	1835
	6675	2100	3015	7590	1990

Special trucks are not included in this overview.

3.5 Tyre type

NOTE

When replacing tyres/rims fitted at the factory, always use original spare parts or tyres approved by the manufacturer. Otherwise the manufacturer's specification cannot be guaranteed.

If you have any queries please contact the manufacturer's customer service department.

Description		DFG/TFG		
		540/545	550	
	SE*	8.25x15	300x15	
Front tyres	Pneumatic*	8.25x15 16PR	300x15 18PR	
FIOHIC LYINGS	Tyre pressure bar	8.5	8.5	
	Torque Nm	580-620	580-620	
	SE*	28x9-15	28x9-15	
Poor tyroo	Pneumatic*	28x9-15	28x9-15	
Rear tyres	Tyre pressure bar	8.5	8.5	
	Torque Nm	500-520	500-520	

^{*)} The models listed in the table correspond to the standard version. Other tyres can be used depending on the truck's equipment.

3.6 Engine Data

DFG 540/545/550

Description	DFG 540	DFG 545	DFG 550	
Cylinder/cubic capacity	4/4400	4/4400	4/4400	cm ³
Rated speed (without load)	2200	2200	2200	rpm
Engine output	56	56	56	kW
Fuel consumption 60 VDI duty cycles/h	4.7	5.2	5.7	l/h [kg/h]

TFG 540/545/550

Description	TFG 540	TFG 545	TFG 550	
Cylinder/cubic capacity	6/4294	6/4294	6/4294	cm ³
Rated speed (without load)	2200	2200	2200	rpm
Engine output	67	67	67	kW
Fuel consumption 60 VDI duty cycles/h	6.24	6.5	6.8	l/h [kg/h]

3.7 EN norms

Noise emission level

DFG 540/545/550: 78 dB (A)*TFG 540/545/550: 78 dB(A)*

*+/- 3 dB(A) depending on the truck's equipment

in accordance with EN 12053 as harmonised with ISO 4871.

The noise emission level is calculated in accordance with standard procedures and takes into account the noise level when travelling, lifting and when idle. The noise level is measured at the level of the driver's ear.

Vibration

DFG 540/545/550: 0,60 m/s²TFG 540/545/550: 0,60 m/s²

in accordance with EN 13059.

The vibration acceleration acting on the body in the operating position is, in accordance with standard procedures, the linearly integrated, weighted acceleration in the vertical direction. It is calculated when travelling over thresholds at constant speed (standard truck version). These recordings were taken on a single occasion and must not be confused with the human vibrations of the "2002/44/EC/Vibrations" operator directive. The manufacturer offers a special service to measure these human vibrations, (see "Human vibration measurement" on page 165).

Electromagnetic compatibility (EMC)

The manufacturer confirms that the truck adheres to the limits for electromagnetic emissions and resistance as well as the static electricity discharge test in accordance with EN 12895 as well as the standardised instructions contained therein.

No changes to electric or electronic components or their arrangement may be made without the written agreement of the manufacturer.



WARNING!


Medical equipment can be damaged by non-ionised radiation

Electrical equipment on the truck emitting non-ionised radiation (e.g. wireless data transmission) can affect operators' medical equipment (pacemakers, hearing aids etc.) and result in malfunctions. Consult with a doctor or the medical equipment manufacturer to clarify whether it can be used near the industrial truck.

3.8 Conditions of use

Ambient temperature

- operating at -20 to 40°C




3.9 Electrical requirements

The manufacturer certifies compliance with the requirements for the design and manufacture of electrical equipment, according to EN 1175 "Industrial Truck Safety - Electrical Requirements", provided the truck is used according to its purpose.

4 Identification points and data plates


Warnings and notices such as capacity charts, strap points and data plates must be legible at all times. Replace if necessary.



Item	Component			
15	Do not travel with raised load or mast tilted forward with a raised load			

Item	Component					
16	Wear seat belt					
17	Strap points for crane lifting					
18	Capacity					
19	Capacity with attachment					
20	Tipover hazard					
21	Fuel					
22	Truck data plate under the engine cover (not shown)					
23	Read operating instructions					
24	Do not stand on load handler / Do not stand under load handler / Risk of					
trapping when mast extended						
25	Max. body size (○)					
26	Test plaque (○)					
27	Jack contact points					
28	Hydraulic oil specification					
29	Noise level					
30	Model description					
31	Do not carry passengers warning					
	Serial number, engraved in chassis below the engine cover					

4.1 Data plate



Item	Description	Item	Description
32	Туре	37	Year of manufacture
33	Serial number	38	Load centre (mm)
34	Rated capacity in kg	39	Net weight in kg
35	Output in kW	40	Manufacturer
36	Option	41	Manufacturer's logo

For queries regarding the truck or ordering spare parts always quote the truck serial number (33).

4.2 Truck capacity plate

CAUTION!

Accident risk from fork replacement

If you replace the forks with ones that differ from the originals, the capacity will change.


- ► When replacing the forks you must attach an additional capacity plate to the truck.
- ► Trucks supplied without forks are given a capacity plate for standard forks (length:

1150 mm)

The capacity plate (18) gives the capacity (Q in kg) of the truck for a vertical mast. The maximum capacity is shown as a table with a given load centre of gravity D (in mm) and the required lift height H (in mm).

The capacity plate (18) of the truck indicates the truck's capacity with the forks as originally supplied.


Example of how to calculate the maximum capacity:



For a load cente of gravity D of 600 mm and a maximum lift height h₃ of 3600 mm the maximum capacity is Q 1105 kg.

Lift height restriction

The arrow shape markings (42 and 43) on the inner and outer masts show the driver when the prescribed lift limits have been reached.



4.3 Attachment capacity plate

The attachment capacity plate is next to the truck's capacity plate and gives the truck's capacity Q (in kg) in conjunction with the respective attachment. The serial number for the attachment indicated on the capacity plate must match the data plate of the attachment.

→

For loads with a centre of gravity greater than 500 mm, the capacities are reduced by the difference of the altered centre of gravity.

5 Stability

The truck's stability has been tested according to latest technological standards. These take into account the dynamic and static tipover forces that can occur if used correctly.

Stability can also be affected by the following factors:

- Tyre type
- Mast
- Attachment
- Transported load (size, weight and centre of gravity)

A

WARNING!

Loss of stability can cause accidents

Changing the components can alter the stability.

C Transport and Commissioning

1 Transport

Transport can be carried out in two different ways, depending on the height of the mast and the local conditions.

- Vertically, with the mast assembled (for low heights)
- Vertically, with the mast dismantled (for large heights), all mechanical connections and hydraulic lines between the basic truck and the mast separated.

2 Truck laden


2.1 Centre of gravity of the truck

↑ WARNING!

Altering the centre of gravity can be hazardous

The overall centre of gravity can vary depending on the truck's equipment (especially the mast version).

- For masts with a low height the centre of gravity will move towards the
- ► For masts with a greater height the centre of gravity will move towards the centre of the truck.



2.2 Lifting the truck by crane

↑ CAUTION!

The mast can get damaged

- ► Loading by crane is only intended for the initial transport before the truck is used for the first time.
- ► Loading must be carried out by specially trained staff in accordance with recommendations contained in Guidelines VDI 2700 and VDI 2703

↑ DANGER!

Crane slings can tear, resulting in accidents

- ▶ Only use crane lifting gear with sufficient capacity.
- ► Loading weight = Net weight of truck (+ battery weight for electric trucks).
- ▶ The mast must be tilted back fully.
- ▶The crane lifting gear on the mast must have a minimum clear length of 2 m.
- ► Crane slings should be fastened in such a way that they do not come into contact with any attachments or the overhead guard when lifting.
- ▶ Do not stand under a swaying load.



Lifting the truck by crane


Requirements

 Park the truck securely, (see "Parking the truck securely" on page 71).

Procedure

- Fasten the crane slings securely to the attachment points (45) and (44).
- Raise and load the truck.
- Lower and deposit the truck carefully ((see "Parking the truck securely" on page 71)).
- Secure the truck with wedges to prevent it from rolling away.

This concludes the loading by crane.



2.3 Loading with another industrial truck

Λ w

WARNING!

The truck can be damaged

The truck to be loaded can get damaged when loading with another industrial truck.

- ▶ Only trained specialist personnel should load the truck.
- ► Use only trucks with sufficient capacity for loading.
- ▶ Only for loading and unloading.
- ▶ The forks of the second industrial truck must be sufficiently long
- ► Transporting over long distances prohibited.

Loading the truck with a second industrial truck

Requirements

- Park the truck securely, (see "Parking the truck securely" on page 71).

Procedure

- Raise the truck with the forks at the side between the axles.
- Raise the truck slightly and make sure it is securely positioned on the forks. If necessary adjust or secure the forks with stops.
- Carefully load/unload the truck, (see "Lifting, transporting and depositing loads" on page 79).
- Lower the truck slowly onto the ground and prevent it from rolling away.

The truck is now loaded.


3 Securing the truck during transport

↑ WARNING!

Accidental movement during transport

Improper fastening of the truck and mast during transport can result in serious accidents.

- ▶ Loading must be carried out by specially trained staff in accordance with recommendations contained in Guidelines VDI 2700 and VDI 2703 In each case correct measurements must be made and appropriate safety measures adopted.
- ▶ The truck must be securely fastened when transported on a lorry or a trailer.
- ► The loading area must have clamp rings and a wooden floor to secure the retaining wedges.
- ▶ Use wedges to prevent the truck from moving.
- ▶ Use only tensioning belts or tie-down straps or with sufficient strength.



Securing the industrial truck for transport

Requirements

 Position the industrial truck securely on a lorry or trailer, (see "Parking the truck securely" on page 71).

Tools and Material Required

- 2 tensioning belts with tensioning device
- Retaining wedges.

Procedure

- Secure the industrial truck with the tensioning belt (46) at the top cross member of the mast (45) and the trailer coupling (44) or over the front mud guards (47) and on the trailer coupling (44).
- Tighten the tensioning belts (46) with the tensioning device.

The industrial truck is now secured for transport.

4 Using the Truck for the First Time

Safety Instructions for Assembly and Commissioning

⚠ WARNING!

Accident risk from incorrect assembly

The assembly of the truck at the application site, commissioning and driver training must only be performed by the manufacturer's customer service representatives who have been specially trained for these tasks.

- ► The hydraulic lines may only be connected to the basic truck / mast interface when the mast has been properly assembled.
- ▶ Only then can the truck be started.
- ▶ If several trucks have been delivered, make sure that the serial numbers of the load handlers, masts and basic trucks always match.

Preparing the truck for operation after delivery or transport

Procedure

- Check the equipment is complete.
- Check the engine oil level.
- Check the hydraulic oil level.
- Check the transmission oil level (only on trucks with hydrodynamic drives).
- Check the brake fluid level (only on trucks with hydrodynamic drives).
- Test the battery connections.
- Check the battery acid level (not for maintenance-free batteries).

The truck can now be started, (see "Preparing the Truck for Operation" on page 59).

D Fuelling the Truck

1 General

1.1 Safety regulations for handling diesel fuel and LPG

↑ WARNUNG!

An unsecured truck can cause accidents The truck can suddenly start to move.

▶ Before filling up or replacing the LPG bottle, park the truck securely, Siehe "Parking the truck securely" auf Seite 71.

↑ WARNUNG!

Accident risk from ignition

- ► Fuels and liquefied petroleum gas can ignite.
- ▶ Smoking, naked flames and other ignition sources are strictly prohibited in the immediate vicinity when handling fuels and LPG.
- ▶ Labels indicating the hazard are must be positioned where they are clearly visible.
- ▶ Do not store flammable materials in this area. Powder fire extinguisher must be provided within easy reach of the filling area.
- ► Use only category A, B or C type powder fire extinguishers to fight LPG fires.
- ▶ Bring any unsealed LPG bottles immediately outside, attach visible markings and notify the supplier.

Storage and Transport

The diesel and LPG storage and transport devices must comply with statutory requirements.

If there is no filling point available, the fuel must be stored and transported in clean, approved containers.

The contents must be clearly indicated on the container.

HINWEIS

Fuel can cause environmental damage

- ▶ Bind any spilled diesel fuel with suitable methods.
- ▶Then dispose of the diesel and fuel filter in accordance with environmental regulations.

Fuel filling and LPG bottle replacement personnel

Personnel filling the trucks or replacing LPG bottles must have sufficient knowledge of the nature of fuels to ensure safe operation.

/\ VORSICHT!

Liquid gas can cause frostbite

- Liquid gas produces frostbite when it comes into contact with bare skin.
- Avoid direct contact with the skin.
- ► Wear gloves.

Filling up LPG containers

LPG containers remain attached to the truck and are filled up at LPG stations. Always follow the instructions of the tank system and LPG container manufacturer as well as statutory and local regulations when filling up.

HINWEIS

Instructions for the safe operation of LPG systems

- ► All maintenance and repair work on LPG systems and containers should be carried out by qualified personnel who have been trained to work on LPG systems.
- The owner must comply with all legal requirements, technical standards and health and safety regulations applicable to liquid gas.
- ▶ Before starting work, the driver must check that all accessible components of the LPG system are in good working order, in accordance with the regulations of the country of use.
- ▶ Do not operate the truck if there is any damage, corrosion, wear or degradation to individual components of the LPG system.


1.2 LPG system relief valve

LPG powered trucks are fitted with a relief valve. This is located on the rear cover next to the gas bottle.

- In the event of a fault the pressure in the gas system is restricted to a maximum level. The relief valve is fitted with a plastic cover (45).
- When the valve is activated the plastic cover comes off, thereby clearly indicating a fault in the gas system.



- The gas system must be check by suitably qualified and trained personnel.
- The user must check that the plastic cover is present each time he uses the truck.



Danger from escaping liquid gas.

Liquid gas can escape from faulty gas hoses.

- ▶ Use only gas bottles with an integrated line break safety valve.
 The gas bottle connection is also fitted with a line break safety valve which prevents the gas from escaping accidentally during operation.
- ► When replacing, always use a gas bottle connection with an integrated line break safety valve.

2 Adding diesel

↑ VORSICHT!

Air in the fuel system will result in malfunctions.

▶ Never allow the fuel tank to run dry.

2.1 Fuelling

MARNUNG!

Diesel fuel can be hazardous

- ▶ Diesel fuel can cause irritation if it comes into contact with the skin. Rinse any affected areas thoroughly.
- ▶ If it comes into contact with the eyes rinse them immediately with flowing water and call for a doctor.
- ► Wear safety gloves when handling diesel fuels.

HINWEIS

► Fuelling must always be performed in designated areas by trained and authorised personnel.

HINWEIS

- ► Capacity: DFG 540 550 = 70 l.
- ▶ Use only DIN EN 590 diesel with a cetane rating above 51. Use of fuels that do not comply with this standard may cause increased ware and damage to the engine and exhaust gas system. Compliance with the required exhaust gas limits might no longer be provided. The company operating the truck is responsible in this case.

2.1.1 Fuelling the tank system

Vorgehensweise

- Park the truck securely before fuelling, (see "Parking the truck securely" on page 71).
- Unscrew the tank cap (49).
- Insert the pump nozzle into the open tank filler neck.
- · Add the fuel.
- Do not overfill the tank.
- Tighten the cap (49) back on after fuelling.

49


Fuelling is now complete.

2.2 Fuelling with fuel containers

Vorgehensweise

- Unscrew the tank cap (49) and open the fuel container.
- Fit the outlet pipe onto the fuel container.
- Insert the outlet pipe into the open tank
- Make sure the fuel container and outlet pipe are connected tightly to each other.
- Raise the fuel container carefully and slowly add the diesel.
- Do not overfill the tank.
- Tighten the cap (49) back on after fuelling.

Fuelling is now complete.



3 LPG containers

Only use liquid gas that complies with DIN 51622 or comparable national regulations.

3.1 LPG bottles

⚠ GEFAHR!

Risk of explosion

▶The LPG bottle must only be replaced at designated areas by trained and authorised personnel.

↑ VORSICHT!

Using unsuitable LPG bottles can cause accidents.


- ► Use only approved LPG bottles.
- ► The LPG bottle must always rest on an engaged bottle holder so that the hose connection of the shutoff valve is facing vertically down.
- ▶ For bottle types of other countries note the national regulations.
- ▶ Note the indications and markings on the LPG bottle.

3.1.1 Using an LPG bottle

Replace the LPG bottle

Vorgehensweise

- Park the truck securely before replacing the LPG bottle, (see "Parking the truck securely" on page 71)
- Close the shut-off valves (50) securely.
- Start the motor and allow the LPG system to run empty in neutral.



Remove the LPG bottle




VORSICHT!

The connection has a left thread

Vorgehensweise

- Unscrew the union nut (54) while holding against the handle (53).
- Remove the hose (56) and immediately screw the valve cap onto the empty LPG bottle.
- Open the toggle-type fastener (52) and fold back the cover (51).
- Carefully remove the LPG bottle (14) from the bracket (55) and place it down securely.




Inserting a new LPG bottle

Vorgehensweise

- Insert the LPG bottle (14) into the bracket (55)
- Align the hose connection downwards.
- Fold back the cover (51) and secure it with tensioning belts. Tighten the toggle-type fasteners (52).
- Unscrew the valve cap.
- Fit the hose (56) in accordance with instructions.
- Carefully open the shut-off valve (50).
- Check the hose connection for leaks using a foam-forming agent.

The replacement is now complete.



3.1.2 Operating with two LPG bottles

↑ WARNUNG!


Visibility is restricted when the truck reverses.

- External mirrors must be fitted on either side of the industrial truck.
- ▶ In addition, a panoramic mirror must be present above the LPG bottles.

Operating the twin bottle system

HINWEIS

Use the additional valve (57) on the bracket (55) to change the gas supply. You can tell which bottle is supplying the gas by the gas hose connection on the shut-off valve (50) and the routing towards the LPG bottles (e.g. RH side of toggle valve = up, LH side of toggle valve = down).



Vorgehensweise

• Use the lever (58) to change between the top and bottom LPG bottles.

Replacing the LPG bottles

Vorgehensweise

- (see "Using an LPG bottle" on page 46).
- Replace an empty LPG bottle at the earliest opportunity with a full one.

Switching off the gas supply

Vorgehensweise

Close both shutoff valves (50) on the LPG bottles to interrupt the supply of LPG.

3.2 Liquid gas tank

Refillable liquid gas tanks contain a dispensing valve (63), a filling stop valve (61), a relief valve (62) and a display (59).


Filling refillable liquid gas tanks (optional equipment).

Voraussetzungen

Note all the filling of LPG bottles on the LPG pump.

Vorgehensweise

- Close the dispensing valve (63).
- Unscrew the cap (60) of the filling stop valve (61).
- Screw the filling connection of the liquid gas pump onto the filling stop valve (61).
 Fuelling automatically ends when the tank's
 - capacity has been reached.
 After fuelling, unscrew the filling connection and screw the cap (60) of the filling stop valve (61) back on.




4 Fuel level indicator

4.1 Display unit

The level indicator (64) shows the capacity of the tank (only for DFG).

If the indicator (64) shows the reserve range, fill the tank. This is also displayed by the spare indicator (65).



4.2 Level indicator for LPG bottles (O)

When the level indicator for LPG bottles (\bigcirc) is lit, this indicates that the LPG bottle is empty.

The remaining travel time will be 8 - 12 minutes, depending on the application and ambient conditions.

Fluctuations in the liquid gas level caused by the travel mode can cause the level indicator to light up briefly. Only a permanently lit level indicator means that the LPG bottle is almost empty.

_ _

E Operation

1 Safety Regulations for the Operation of the Forklift Truck

Driver authorisation

The truck may only be used by suitably trained personnel, who have demonstrated to the proprietor or his representative that they can drive and handle loads and have been authorised to operate the truck by the proprietor or his representative.

Driver's rights, obligations and responsibilities

The driver must be informed of his duties and responsibilities and be instructed in the operation of the truck and shall be familiar with the operating instructions. The driver shall be afforded all due rights. Safety shoes must be worn for pedestrian operated trucks.

Unauthorised use of truck

The driver is responsible for the truck during the time it is in use. The driver must prevent unauthorised persons from driving or operating the truck. Do not carry passengers or lift other people.

Damage and faults

The supervisor must be immediately informed of any damage or faults to the truck or attachment. Trucks which are unsafe for operation (e.g. wheel or brake problems) must not be used until they have been rectified.

Repairs

The driver must not carry out any repairs or alterations to the truck without the necessary training and authorisation to do so. The driver must never disable or adjust safety mechanisms or switches.

Hazardous area

A

WARNING!

Risk of accidents / injury in the hazardous area of the truck

The hazardous area is defined as the area in which a person is at risk due to truck movement, lifting operations, the load handler (e.g. forks or attachments) or the load itself. This also includes areas which can be reached by falling loads or lowering operating equipment.

- ▶ Instruct unauthorised people to leave the hazardous area.
- ▶ Give a warning signal with plenty of time for people to leave.
- ▶If unauthorised personnel are still within the hazardous area stop the truck immediately.



DANGER!

Accident risk

► The driver must remain within the protected area of the overhead guard while the truck is being operated.

Safety devices and warning labels

Safety devices, warning signs ((see "Identification points and data plates" on page 30)) and warning instructions in the present operating instructions must be strictly observed.




CAUTION!

Reduced headroom can cause injuries

- ▶ Trucks with reduced headroom are equipped with a warning label within the driver's line of sight. The max. recommended body size indicated on this sign must be observed.
- ▶The headroom is also reduced when you wear a protective helmet.

2 Displays and Controls




Item	Control / Display		Function
66	Emergency Disconnect switch	•	Switches control current on and off in emergencies
67	Slow travel / brake pedal	•	1st zone: controls slow travel. 2nd zone: applies service brake.
68	Brake pedal		Upon activation, the truck brakes to a halt immediately.
69	Accelerator pedal	•	Controls the engine speed and / travel and lift speeds.
70	Steering wheel	•	Steering the industrial truck.
71	Travel direction switch/	•	 Selects travel direction / neutral position
	gear selector		Gear selection
72	Steering column adjusting lever	•	Adjusts the steering column tilt.
73	Parking brake lever	•	To apply / release the parking brake:
			Pull up lever to engage.
			Push lever forward to release.
74	SOLOPILOT	•	Operates the following functions:
			Load lifting lift/lower
			Load lifting lift/lowerMast forward / reverse tilt
			Sideshifter left / right (○)
			Auxiliary hydraulics (○)
75	Options switch	•	Options
76	Horn	•	Activates an audible warning.
77	Key switch	•	Switches power supply on and off. Starts and stops the engine.
			O - All main circuits are switched off and the key can be removed.
			I - All consumers off
			II -All consumers on pre-heat - Pre-heat
			III - Starting the motor (automatically returns to the II position).

●= Series equipment ○= Optional equipment	
---	--

2.1 Display unit

The control panel display unit shows the operating data, the battery charge, the service hours and error details and information. Pictograms in the left top section of the control panel act as warning indicators.

2.1.1 Graphical displays




Item		Control / Display		Function
64		Fuel display (DFG)	•	Graphic illustration of the fuel supply.
65	(Fuel supply indicator (DFG)	•	When lit, indicates the fuel supply is too low.
78	(P)	Parking brake warning indicator	•	Parking brake activated - Truck operational, parking brake active.
79		Coolant temperature display	•	Indicates the coolant temperature.
80		Brake fluid indicator	•	When lit, indicates the brake fluid level is too low.

Item		Control / Display		Function
81		Not used		
82	A	Dipped lights	•	Switches dipped lights on and off.
83	•	Engine oil pressure display	•	When lit, indicates that the engine oil pressure is too low.
84		Not used	0	
85		Converter temperature indicator		When lit, indicates that the oil temperature in the power shift transmission is too high.
86		Seat belt indicator	0	When lit indicates that the seat belt has not been properly attached.
87	₹	Flashing indicator	0	Right / left indicator lamps activated
88	M	Neutral position	•	When lit, indicates that the travel direction switch is in neutral.
89	ERRENE T	Time / service hours display	•	Indicates the time or number of operating hours in service.
90	(ag)	Pre-heat indicator lamp	•	Engine is preheated (DFG only).
91		Charge current indicator	•	Battery not charging.

●= Series equipment	○= Optional equipment
3 3 3 1 1 3 3 3 3 3 1 1 3 1 3 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 1 3 1 3 1 1	

2.2 Instrument panel switches (O)



	Display	Function
	Rear windscreen wiper	Switches rear windscreen wiper on and off.
	Front windscreen washing system	Switches the front windscreen washing system on and off.
8	Front windscreen wiper	Switches the window wiper on and off.
P€	Parking light	Switches parking light on and off.
	Rear work lights	Switches rear work lights on and off.
	Dipped lights	Switches dipped lights on and off.
②	Front work lights	Switches front work lights on and off.
(A)	Warning indicator	Switches the warning indicator on and off.
	Rear windscreen heating	Switches rear windscreen heating on and off.

The arrangement of switches and buttons on the dashboard and engine cover is customised to customer preference.

2.3 Travel direction switch/gear selector

2.3.1 Travel direction switch


NOTE

The engine will not start when the travel direction switch is in the forward or reverse position.

When the travel direction switch is in the middle position, the gear is in neutral.


Procedure

- To select the forward gear, push the travel direction switch forward.
- To select the reverse gear, push the travel direction switch back.



2.3.2 Gear selector

Gears are selected manually. When travelling on a slope, press 'I' to select a lower gear.



3 Preparing the Truck for Operation

3.1 Checks and operations to be performed before starting daily operation

↑ WARNING!

Damage and other truck or attachment (special equipment) defects can result in accidents.

If damage or other truck or attachment (special equipment) defects are discovered during the following checks, the truck must be taken out of service until it has been repaired.

- ▶ Report any defects immediately to your supervisor.
- ► Tag out and decommission a faulty lift truck.
- ▶Only return the truck to service when you have identified and rectified the fault.

↑ CAUTION!


Checking the accelerator pedal

► The accelerator pedal should only be checked when the parking brake is applied and the engine is idle.

Inspection before starting daily operation

Procedure


- Visually inspect the entire truck (in particular wheels, wheel bolts and load handler) for damage.
- Check the fork stop (92) and fork tine retainer (93).
- Visually inspect the hydraulic system in the visible area for damage and leaks.
- Check the driver's seat has been adjusted to the correct position.
- Test the horn and reversing buzzer (○) where applicable.
- Check that the load chart and warning labels are legible.
- Test the controls and displays.
- Test the steering.
- Make sure the load chains are evenly tensioned.
- Test the seat belt. (The belt should block if extracted suddenly.)
- Test the seat switch. When the driver's seat is vacated it should not be possible to activate the working hydraulics.
- Test the restraint system (○),
- Test the lift/lower, tilt and if applicable the attachment hydraulic control functions.
- Check the accelerator pedal can move freely by pressing it several times.
- Test the service and parking brakes: Approach carefully and test the effectiveness of the brake pedal.
- Check the fuel supply.
- Check the fluid level of the windscreen washer system (○), (see "Adding window washer system fluid" on page 150).
- Check the gas system is working correctly, (see "LPG containers" on page 46) https://www.besttruckmanuals.com/



3.2 Entry and exit

Procedure

- Open the cab door (○)
- To enter and exit the cab, hold onto the handle (94).



An additional step is provided for the driver position extension (O)


3.3 Trucks with reduced headroom X (O)


⚠ WARNING!

An unsuitable workplace can damage your health

Failure to observe the recommended body size can cause stress and endanger the driver and may lead to lasting ill health due to an unhealthy posture and excessive strain on the driver.

- ► The owner must ensure that truck operators do not exceed the maximum body size indicated.
- The owner must check that the drivers can sit in a ingreal and upright position





3.4 Setting up the operator position

Λ

WARNING!

Accident risk

▶ Do not adjust the driver's seat while travelling.

Procedure

- Before starting to travel, adjust the driver's seat, steering column and armrest (if
 necessary), so that all the controls are within reach and can be applied without
 naving to strain.
- Adjust the visibility aid equipment (mirrors, camera systems etc.) so that the working environment can be clearly seen.

3.4.1 Adjusting the driver's seat

A

WARNING!

Risk of accidents and damage to health

An incorrectly adjusted driver's seat can result in accidents and damage to health.

- ▶ Do not adjust the driver's seat while travelling.
- ▶ The driver's seat should lock in position after adjustment.
- ▶ Check and adjust the individual driver's seat setting before starting to use the truck.
- ► Hold the weight setting lever (95) only by the recess, do not reach through underneath the lever.

Adjusting the driver's weight

NOTE

To achieve optimal seat cushioning the driver's seat must be set to the driver's weight.

Set the driver's weight when the seat is occupied.

Procedure

- Fold out the weight adjustment lever (95) as far as it will go in the arrow direction
- Move the weight adjustment lever (95) up and down to set the seat to a higher weight.
- Move the weight adjustment lever (95) up and down to set the seat to a lower weight.
 - The driver's weight is correct when the arrow is in the middle of the display window (96). The minimum or maximum weight setting is reached when you can feel a return stroke on the lever.
- After setting the weight, move the lever (95) back in full.

The driver's weight is now set.

Adjusting the backrest

Procedure

→

- Sit on the driver's seat.
- Pull the lever (98) to adjust the backrest.
- Adjust the backrest tilt.
- Release the lever (98) again. The backrest is locked.

The backrest is now set.

Hold the weight setting lever (95) only by the recess, never reach through underneath the lever.

Driver's seat with pneumatic weight adjustment (MSG 75) (O)

Procedure

- Pull the weight adjustment lever (95) up to set the seat to a higher weight.
- Push the weight adjustment lever (95) down to set the seat to a lower weight.

The driver's weight is correct when the arrow is in the middle of the display window (96).

Adjusting the seat position


A

CAUTION!

An unsecured driver's seat can cause injury

An unsecured driver's seat can slide out of its guide during travel, resulting in

- The driver's seat must be locked in position.
- ► Do not adjust the driver's seat while travelling.



Procedure

- Sit on the driver's seat.
- Pull up the driver's seat locking lever97 in the direction of the arrow.
- Push the driver's seat forwards or backwards to the desired position
- Engage the driver's seat locking lever (97) in position.

The seat position is now correctly set.

Adjusting the lumbar vertebrae support (O)

Procedure


• Turn the hand wheel (100) to the required position.

Position 0 = no warping in lumbar vertebrae area.

Position 1 = increasing warping in upper lumbar vertebrae area.

Position 2 = increasing warping in lower lumbar vertebrae area.

The lumbar vertebrae support is now set.



3.4.2 Adjusting the steering wheel / steering column

↑ CAUTION!


Do not adjust the steering wheel while travelling

Individual steering wheel position

The tilt of the steering wheel can adjusted to suit the operator.

Procedure

- Pull the steering wheel adjusting lever (101) in the direction of the arrow (103).
- Tilt the steering wheel (3) forward or backward as required.
- Push the steering wheel adjusting lever (102) in the direction of the arrow.




3.4.3 Adjusting the armrest (O)

Procedure

- Loosen the screw (104) and tilt the armrest up or down.
- Re-tighten the screw (104).
- Loosen the screw (105) and set the armrest vertical.
- Re-tighten the screw (105).
- Loosen the screw (106) and set the armrest horizontal.
- Re-tighten the screw (106).

The armrest is now positioned.



3.5 Seat Belt

⚠ DANGER!

Travelling without a seat belt increases the risk of injury.

If the seat belt is not worn or is modified, personal injury can result.

- ► Always put on the seat belt before starting the industrial truck.
- ▶ Do not modify the seat belt.
- ▶ Damaged or non-operational seat belts must be replaced by trained personnel.
- ► Seat belts must always be replaced after an accident.
- ▶ Only original spare parts must be used for retrofits or repairs.
- Protect the seat belt from contamination (e.g. cover it when the truck is idle) and clean it regularly. Frozen belt locks or pulleys must be thawed out and dried to prevent them from freezing up again.

The temperature of the warm air should not exceed +60 °C!

Starting the industrial truck on steep slopes

The automatic blocking system locks the belt in the retractor when the truck is positioned on a steep slope. This prevents the belt from being pulled out of the retractor.

Carefully drive the truck off the slope and then put on the belt.

4 Industrial Truck Operation

4.1 Safety regulations for truck operation

Travel routes and work areas

Only use lanes and routes specifically designated for truck traffic. Unauthorised third parties must stay away from work areas. Loads must only be stored in places specially designated for this purpose.

The truck must only be operated in work areas with sufficient lighting to avoid danger to personnel and materials. Additional equipment is necessary to operate the truck in areas of insufficient lighting.

↑ DANGER!

Do not exceed the permissible surface and spot load limits on the travel routes. At blind spots get a second person to assist.

The driver must ensure that the loading dock / ramp cannot move or come loose during loading / unloading.

NOTE

Loads must not be deposited on travel or escape routes, in front of safety mechanisms or operating equipment that must be accessible at all times.

Travel conduct

The driver must adapt the travel speed to local conditions. The truck must be driven at slow speed when negotiating bends or narrow passageways, when passing through swing doors and at blind spots. The driver must always observe an adequate braking distance between the forklift truck and the vehicle in front and must be in control of the truck at all times. Abrupt stopping (except in emergencies), rapid U turns and overtaking at dangerous or blind spots are not permitted. Do not lean out or reach beyond the working and operating area.

Hazardous situations

on with both hands. Tilt your body in the opposite direction of fall.

Travel visibility

The driver must look in the direction of travel and must always have a clear view of the route ahead. Loads that affect visibility must be positioned at the rear of the truck. If this is not possible, a second person must walk alongside the truck as a lookout to observe the travel route while maintaining eye contact with the driver. Proceed only at walking pace and with particular care. Stop the truck as soon as you lose eye contact.

Negotiating slopes and inclines

Negotiating slopes or inclines up to 15% is only permitted if they are specifically designed as travel routes, are clean and have a non-slip surface and providing they can be safely travelled along in accordance with the truck's technical specifications. The truck must always be driven with the load unit facing uphill. The industrial truck must not be turned, operated at an angle or parked on inclines or slopes. Inclines must only be negotiated at slow speed, with the driver ready to brake at any moment. Particular care is required when travelling near slopes and quay walls.

Negotiating lifts and docks

Lifts may only be entered if they have sufficient capacity, are suitable for driving on and authorised for truck traffic by the owner. The driver must satisfy himself of the above before entering these areas. The truck must enter lifts with the load in front and must take up a position which does not allow it to come into contact with the walls of the lift shaft. People travelling in the lift with the forklift truck must only enter the lift after the truck has come to a halt and must exit the lift before the truck. The driver must ensure that the loading ramp / bridge cannot move or come loose during loading / unloading.

Type of loads to be carried

The operator must make sure that the load is in a satisfactory condition. Loads must always be positioned safely and carefully Use suitable precautions to prevent parts

Inflammable liquids (e.g. fused metal etc.) may only be transported with suitable auxiliary equipment. Contact your authorized Jungheinrich customer adviser.

→

For safety instructions on the nature of loads to be carried with attachments, (see "Lifting, transporting and depositing loads" on page 79).

Towing trailers

The truck may only be used occasionally to tow trailers, (see "Towing trailers" on page 93)

Exhaust emissions can be fatal

- ► The truck must only be operated in well ventilated areas. If the truck is operated in enclosed areas, this can lead to a build-up of harmful exhaust emissions, resulting in dizziness, tiredness and even death.
- ▶ The user must comply with legal requirements, technical standards and health and safety regulations when operating an IC motor powered lift truck in closed rooms.

4.2 Preparing the truck for operation

Before starting the truck


→

The truck should only be operated from the driver's seat. Do not run up the engine in idle. The engine soon reaches operating temperature at a moderate charge and when the speed alternates. Only fully

charge the engine once it has reached operating temperature.

Requirements


 Checks and operations to be performed before starting daily operation, (see "Checks and operations to be performed before starting daily operation" on page 59).



Switching on the industrial truck

Procedure

- Unlock the Emergency Disconnect switch (107). To do this, raise the flap (108) and pull up the Emergency Disconnect switch
- Apply the parking brake.
- Set the travel direction switch (71) to neutral N. Otherwise the motor cannot be started.
- Perform the appropriate starting procedure depending on the type of motor; see 4.2.1 "Starting procedure for the DFG" or 4.2.2 "Starting procedure for the TFG".



4.2.1 Starting procedure for the DFG


Procedure


- Insert the key in the key switch (77). Set key switch to "II".
- All the indicators light up briefly to test operation.
- All the indicators except for the engine oil pressure display (83), parking brake indicator (78), indicator lamp for neutral (88) and charge current indicator (110) should go out after a short while. If not, stop the start-up process and rectify the fault.
 - Turn the ignition/starter switch further to the PRE-HEAT setting and hold it there for about 4 seconds.
 - Now set the ignition / starter key to the "III" position.
- Only apply the starter for a maximum of 15 seconds without interruption. The

thechanism which presents blocking starting again while the engine is running.

- Release the key as soon as the engine starts. It automatically reverts to the "II" setting.
- All indicators lights except for neutral setting (88) and parking brake (78), if activated, should go out as soon as the engine starts. If not, stop the engine immediately and rectify the fault.

The truck is now ready for operation.





4.2.2 Starting procedure for the TFG


△ DANGER!

Risk of escaping liquid gas if the truck does not start

- ► Note the safety regulations governing the handling of liquid gas ((see "Safety regulations for handling diesel fuel and LPG" on page 41))
- ► Close the gas bottle shut-off valve.
- ► Set the key switch to "O"
- ► Notify your superior.


Procedure

- Slowly open the shut-off valve on the LPG bottle.
- Insert the key in the key switch (77). Set key switch to "II".
- All the indicators light up briefly to test operation.
- All the indicators except for the engine oil pressure display (83), parking brake indicator (78), indicator lamp for neutral (88) and charge current indicator (110) should go out after a short while. If not, stop the start-up process and rectify the fault.



- Now set the ignition / starter key to the "III" position.
- Only apply the starter for a maximum of 15 seconds without interruption. The truck contains a restart blocking mechanism which prevents it from starting again while the engine is running.
 - Release the key as soon as the engine starts. It automatically reverts to the "II" setting.
- All indicators lights except for neutral setting (88) and parking brake (78) should go out as soon as the engine starts. If not, stop the engine immediately and rectify the fault.

The truck is now ready for operation.



4.3 Parking the truck securely

↑ DANGER!

Risk of explosion

▶LPG trucks may only be parked in ground level rooms or higher and providing they are adequately ventilated. They must not be parked near to cellar doors and entry points, hollows, drains, drain inlets or other recesses below the parked truck.

MARNING!

An unsecured truck can cause accidents


Parking the truck on an incline, without the brakes applied or with a raised load / load handler is dangerous and is strictly prohibited.

- Always park the truck on a level surface. In special cases the truck may need to be secured with wedges.
- ► Always fully lower the mast and load handler.
- ► Tilt the mast forward.
- ► Select a place to park where no other people are at risk of injury from lowering forks.
- ▶ Do not park and abandon the truck on an incline.

Parking and leaving the truck

Procedure

- Apply the parking brake, (see "Parking brake" on page 76).
- Lower the load handler.
- Turn the key in the key switch (77) to the "0" position.
- Remove the key from the key switch (77).
- Press the Emergency Disconnect switch (107) down.
- Close the gas bottle (TFG only).





TFG only: If the ignition key is set to "0" while the engine is running, the engine will continue to run for a short time. This ensures that the remaining gas in the lines between the engine and the automatic shutoff valve of the gas system is used up. If the engine has accidentally switched off, start up the engine and switch it off again in the correct manner at the end of the journey.

4.4 Emergency Disconnect

A

CAUTION!

Accident risk

The operation of the Emergency Disconnect switch must not be affected by any objects placed in its way.

Applying the Emergency Disconnect

Procedure

Press the Emergency Disconnect switch (107) down.

All electrical functions are deactivated. The truck coasts.



4.5 Travel

⚠ WARNING!

Improper travel can result in accidents

- ▶ Do not get up from the driver's seat during travel.
- ▶ Do not drive the truck unless your are wearing a seat belt and the panels and doors are properly locked.
- ► Make sure that the travel area is clear.
- ▶ Adapt the travel speed to the conditions of the route, the work area and the load.
- ▶ Tilt the mast back and raise the fork carriage approx. 200 mm.
- ► Make sure you have enough visibility when reversing.

Travel

Requirements

 Truck prepared for operation, (see "Preparing the truck for operation" on page 68).

Procedure

- Release the parking brake.
- Choose the travel direction with the travel direction switch (71).

NOTE


Only change direction when the truck has stopped.

- To select the forward gear, push the switch forward.
- To select the reverse gear, pull the switch back.
- Raise the fork carriage approx. 200 mm.
- Tilt the mast back.
- Apply the accelerator pedal (69). The travel speed is governed by the accelerator (69).

The truck travels in the direction selected.

Neutral locking

If the driver leaves the truck without taking it out of gear, the truck will automatically be set to neutral. To resume travel (sitting on the truck) all controls must be deactivated, the travel direction switch must be set to neutral "N" and then the required direction selected.



Slow travel / brake pedal

Requirements

 Truck ready for operation, (see "Preparing the truck for operation" on page 68).

Procedure

Apply the slow travel / brake pedal (67) sensitively.

The Industrial truck moves slowly in the selected travel direction and allows for excellent shunting in confined areas. Rapid lifting is possible at a slow travel speed.



NOTE

The slow travel / brake pedal can also actuate the drum brakes but this is only intended as a crawl speed aid. The pedal should not be used as a service brake. This operating mode can only be used for max. 5 seconds when the engine is running at high speed.


4.6 Steering

Steering

Procedure

- Very little steering effort is required; you should therefore turn the steering wheel (70) sensitively.
 - To negotiate a right-hand bend: Turn the steering wheel clockwise according to the required steering radius.
 - To negotiate a left-hand bend: Turn the steering wheel anti-clockwise according to the required steering radius.

The truck travels in the direction selected.



4.7 Brakes

↑ WARNING!

Accident risk

The brake pattern of the truck depends largely on the ground conditions.


- ► The driver must be aware of travel route conditions and them into account when braking.
- ▶ Brake with care to prevent the load from slipping.
- ► Allow for increased braking distance when travelling with an attached load.

4.7.1 Service brake

The brake pedal hydraulically actuates the drum brakes of the front wheels.

When the brake pedal (68) is applied the drum brakes are applied without disengaging the transmission.

Applying the slow travel / brake pedal (67) controls the flow of power in the power shift gear. This pedal can also be used to brake gently during crawl speed operations.




4.7.2 Parking brake

△ DANGER!

Accident risk

- ► The parking brake will hold the truck with maximum load on a clean ground surface, on inclines of up to 15%.
- ▶ Do not park and abandon the truck on an incline.
- ► Applying the parking brake during travel will cause the truck to brake to a standstill. This may cause the load to slide off the forks tines. There is a higher risk of accidents and injury!
- ► When leaving the industrial truck, always engage the parking brake. An audible warning will sound if the parking brake is not applied.
- The parking brake can be used as an emergency brake.

- Pull back the parking brake lever (73) beyond the pressure point as far as the stop. The parking brake is engaged and the parking brake lever
- is locked in this position.
 Press the release knob (111) and push the parking brake lever forward to release the parking brake.



4.8 Adjusting the forks

Λ

WARNING!

Trapping hazard

There is a trapping hazard when you perform this operation.

► Wear work gloves and safety shoes.




WARNING!

Unsecured and incorrectly adjusted forks can cause accidents

Before adjusting the forks make sure the retaining bolts (93) are fitted.

- ► Adjust the forks so that both forks are equidistant from the outside edge of the fork carriage.
- ► Engage the locking pin in a groove to prevent the forks from moving
- ► The load centrally centre of gravity must be located centrally between the forks.



Adjusting the forks

Requirements

 Park the truck securely, (see "Parking the truck securely" on page 71).


Procedure

- Lift up the locking lever (112).
- Push the forks (113) into the correct position on the fork carriage (114).



- To lift the load securely, the forks (113) must be spread as far apart as possible and positioned centrally with respect to the fork carriage. The load centre of gravity must be of
- carriage. The load centre of gravity must be centrally aligned between the forks (113).
- Lift the locking lever down (112) and move the forks until the locking pin engages in a slot.

The forks are now adjusted.



4.9 Replacing the forks

↑ WARNING!

Unsecured forks can cause injury

You can injure your legs when replacing the forks.

- ► Never pull the forks towards your body.
- ► Always push the forks away from your body.
- ► Secure heavy forks with lifting slings and a crane before pushing them down from the fork carriage.
- ▶ After replacing the forks fit the retaining bolts (93) and make sure the bolts are seated correctly. Retaining bolt torque: 85 Nm.

↑ WARNING!

Trapping hazard

There is a trapping hazard when you perform this operation.

► Wear work gloves and safety shoes.

Replacing the forks


Requirements

 Load handler lowered and forks not touching the ground.

Procedure

- Disassemble the retaining bolts (93).
- Loosen the fork stop (92).
- Carefully push the forks off the fork carriage.

The forks are now dismantled from the fork carriage and can be replaced.



4.10 Lifting, transporting and depositing loads

↑ WARNING!

Unsecured and incorrectly positioned loads can cause accidents

Before lifting a load unit the driver must make sure that it has been correctly palletised and does not exceed the truck's capacity.

- ▶ Instruct other people to move out of the hazardous area of the truck. Stop working with the truck if people do not leave the hazardous area.
- ▶ Only carry loads that have been correctly secured and positioned. Use suitable precautions to prevent parts of the load from tipping or falling down.
- ▶ Do not transport loads other than on the authorised load handler.
- ▶ Damaged loads must not be transported.
- ▶ If the stacked load obscures forward visibility, then you must reverse the truck.
- ► Make sure you have enough visibility when reversing.
- ▶ Never exceed the maximum loads specified in the capacity chart.
- ▶ Never stand underneath a raised load handler.
- ▶ Do not stand on the load handler.
- ▶ Do not lift other people on the load handler.
- ▶ Do not reach through the mast.
- ► Check the fork spread before lifting the load and adjust if necessary.
- ▶ Insert the forks as far as possible underneath the load.

Lifting load units

Requirements

- Load unit correctly palletised.
- Fork spread for the pallet checked and adjusted if necessary.
- Load unit weight matches the truck's capacity.
- Forks evenly loaded for heavy loads.

- Drive the truck carefully up to the pallet.
- Set the mast vertical.
- Slowly insert the forks into the pallet until the fork shank touches the pallet.
- Raise the load handler.
- Reverse carefully and slowly until the load unit is outside the storage area. Make sure you have enough clear space to reverse into.

NOTE

Loads must not be deposited on travel or escape routes, in front of safety mechanisms or operating equipment that must be accessible at all times.

Transporting load units

Requirements

- Load unit correctly lifted.
- Load handler lowered for transport (approx. 150 200 mm above the ground).
- Mast tilted back fully.

Procedure

- Accelerate and decelerate gradually.
- Adapt your travel speed to the conditions of the route and the load you are transporting.
- Watch out for other traffic at crossings and passageways.
- Always travel with a lookout at blind spots.
- On slopes and inclines always carry the load facing uphill, never approach at an angle or turn.


Depositing load units

Requirements

Warehouse location suitable for storing the load.

Procedure

- Set the mast vertical.
- Drive carefully up to the storage location.
- Carefully lower the load handler so that the forks are clear of the load.



• Carefully remove the forks from the pallet.

The load unit is lowered.

4.11 Operating the lift mechanism and integrated attachments

↑ WARNING!

Accident risk when operating the lifting device and integrated attachments

Other people can be injured in the truck's hazardous area.

The hazardous area is defined as the area in which people are at risk from the truck movement, the load handler, attachments etc. This also includes areas which can be reached by falling loads or lowering operating equipment.

Apart from the operator (in the normal operating position) there should be no other people in the truck's hazardous area.

- ▶ Instruct other people to move out of the hazardous area of the truck. Stop working with the truck if people do not leave the hazardous area.
- ► The truck must be prevented from being used by unauthorised people if people do not leave the hazardous area despite the warning.
- ▶Only carry loads that have been correctly secured and positioned. Use suitable protection measure to prevent parts of the load from tipping or falling down.
- Never exceed the maximum loads specified in the capacity chart.
- ► Never stand underneath a raised load handler.
- ▶ Do not stand on the load handler.
- ▶ Do not lift other people on the load handler.
- ▶ The controls should only be operated from the driver's seat, and never suddenly.
- ▶The driver must be instructed in how to operate the lifting device and the attachments.

NOTE

When the driver's seat is not occupied, the control lever is mechanically locked in centre position.

If the driver leaves the industrial truck without moving the travel direction switch to the neutral, the control block will remain locked in the centre position at first when the driver returns to the driver's seat. The control lever is not released again until the driver has moved the travel direction switch to the neutral. This safety function also takes effect if the driver gets up off the seat for longer than 1.5 seconds without leaving the vehicle. In this case as well the transmission must be switched once to neutral. If the industrial truck is equipped with belt lock control (\bigcirc) the belt must also be closed again to release the control lever.


When the controls are released they automatically revert to neutral and the lifting mechanism remains in the position it has reached.


When the mechanical end stop has been reach for the relevant functions (there will be a noise from the pressure relief valve) immediately move the control lever back to its original position.

Controlling the speed of the lifting device

Moving the lever and changing the engine speed governs the operating speed of the hydraulic cylinders. When the levers (116, 115) are released they automatically revert to neutral and the lifting device remains in the position it has reached.

- Set the travel direction switch (71) to neutral.
- Increase the motor speed with the accelerator pedal (69) and
- Keep moving the lever back to increase the speed of the lifting device.
 The engine speed does not affect the





4.11.1 Operating the lift mechanism with the SOLO PILOT


Lifting and lowering

Requirements

- To prepare the truck for operation, (see "Preparing the truck for operation" on page 68)

- Procedure
 Pull the Solo-Pilot lever (117) in direction H to raise the load.
- Push the Solo-Pilot lever (117)in direction S to lower the load.

The load is now raised / lowered.



117

→ When the limit position for the operation has been reached (there will be a noise from the pressure relief valve) release the lever. The lever will revert automatically to neutral.

Tilting the mast forward / backward


Requirements


 To prepare the truck for operation, (see "Preparing the truck for operation" on page 68)

Procedure

- Pull the Solo-Pilot lever (118) in direction R to tilt the mast back.
- Push the Solo-Pilot lever (118) in direction V to tilt the mast forward.

The mast is now tilted back / forward.






Positioning the integrated sideshift (option)


Requirements

 Truck prepared for operation, (see "Preparing the truck for operation" on page 68).

Procedure

- Pull the SOLO-PILOT lever (119) in direction R to move the load handler to the right (from the driver's viewpoint).
- Push the SOLO-PILOT lever (119) in direction V to move the load handler to the left (from the driver's viewpoint).





→

When the limit position for the operation has been reached (there will be a noise from the pressure relief valve) release the lever. The lever will revert automatically to neutral.

Positioning the forks with an integrated fork adjuster (option)

A

CAUTION!

Do not use the fork adjuster to clamp loads.

Requirements

 Truck prepared for operation, (see "Preparing the truck for operation" on page 68).

Procedure

- Press the toggle switch (120) and at the same time pull the Solo Pilot (121) in direction Z: the forks will move towards each other.
- Press the toggle switch (120) and at the same time push the Solo Pilot (121) in direction A: the forks will spread apart.

120

The forks are now positioned.

Synchronising the alignment of the fork tines with an integrated fork adjuster (optional equipment)

Requirements

- Truck ready for operation, (see "Preparing the truck for operation" on page 68).
- The fork tines are no longer aligned.

Procedure

• Press the toggle switch (120) and at the


areaitima pushsibe a Pluck Plant of a paint as far as they will go.

 Press the toggle switch (120) and at the same time pull the SOLO-PILOT (121) in direction Z and bring the fork tines as close to each other as they will go.

The fork tines are now synchronised.



When the limit position for the operation has been reached (there will be a noise from the pressure relief valve) release the lever. The lever will revert automatically to neutral.



4.12 Safety instructions for operating additional attachments

Optionally, trucks can be fitted with one or more auxiliary hydraulic functions to operate attachments. The auxiliary hydraulics are indicated with HF4 and HF5. Auxiliary hydraulic functions for exchangeable equipment are fitted with replacement couplings on the fork carriage. To fit exchangeable equipment (see "Fitting additional attachments" on page 91).

↑ DANGER!

Attaching exchangeable equipment can result in accidents.

Other people can be damaged by attaching exchangeable equipment. Use only exchangeable equipment which has been deemed safe after a risk analysis carried out by the owner.

- ▶ Only use attachments with a CE mark.
- ▶ Only use attachments that have been designed by the attachment manufacturer for use with the respective industrial truck.
- ▶ Only use attachments that have been fitted for the purpose by the owner.
- ► Make sure the operator has been instructed in the use of the attachment and that he uses it for its correct purpose.
- ▶ Re-assess the residual capacity of the truck and if it has been altered, attach an additional capacity plate to the truck.
- ▶ Note the attachment manufacturer's operating instructions.
- ▶ Only use attachments that do not restrict visibility in the travel direction.
- If visibility in the travel direction is impaired, the owner must carry out a risk analysis to assess whether the truck needs to be fitted with auxiliary equipment such as a camera system or mirrors. If such equipment is used, spend sufficient time practicing travelling with them.

Safety instructions for sideshifter and fork adjuster attachments

A

WARNING!

When using multi fork adjusters (multi pallet clamps), restricted visibility and reduced lateral tilt resistance can result in accidents.

- ► Adapt the travel speeds to the visibility and load.
- ► Make sure you have enough visibility when reversing.

Safety instructions for clamping attachments (e.g. baling clamps, barrel clamps, grabs etc.)



WARNING!

Falling loads can cause accidents

This can result in malfunctions and the load can fall accidentally.

- ► Clamping attachments may only be added to trucks which have a button to enable additional hydraulic functions.
- ► Clamping attachments must only be operated on trucks will auxiliary hydraulics HF4 or HF5.
- ▶When connecting the attachment make sure that the hydraulic lines of the attachment ports, (see "Fitting additional attachments"

Safety instructions for rotary attachments



WARNING!

A non-centred centre of gravity can result in accidents

When using rotary devices and non-centred loads, the centre of gravity can be displaced from the centre with a high risk of accidents.

- ► Adapt the travel speed to the load.
- ► Lift the load from the centre.

Safety instructions for telescopic attachments



WARNING!

Accident risk from increased tipover hazard and reduced residual capacity

There is a greater tipover risk with extended telescopic attachments (e.g. reach carriages, telescopic forks, telescopic crane booms).

- ▶ Only use the telescopic function for stacking and retrieving.
- ► Always retract the attachment fully during transport.
- ► Adapt the travel speed to changed load centre of gravity.

Safety instructions for attachments when transporting suspended loads

△ WARNING!

Swinging loads and a reduced residual capacity can result in accidents

- ► Adapt the travel speed to the load, less than walking pace.
- ► Secure swinging loads for example with lifting slings.
- ▶ Reduce the residual capacity and have it certified by a expert.

Safety instructions for using loading buckets as attachments



WARNING!

Greater mast loading can cause accidents.

▶When carrying out the daily checks and operations before starting, (see "Checks and operations to be performed before starting daily operation" on page 59), in particular attention check the fork carriage, mast rails and mast rollers for damage.

Safety notices for fork extensions:

A

WARNING!

Unsecured and excessive fork extensions can cause accidents.

- ► For fork extensions with an open cross sectional area, only carry loads that are resting along the entire length of the fork extension.
- ▶ Only use fork extensions with the same fork cross section and minimum fork length of the truck and which comply with the details on the fork extension data plate.
- ▶ The basic fork length must be at least 60% of the length of the fork extension.
- ► Lock the fork extensions onto the basic forks.
- ▶When carrying out the daily checks and operations before starting, (see "Checks and operations to be performed before starting daily operation" on page 59), also check the fork extension lock.
- ► Mark any fork extensions with an incomplete or faulty lock and take them out of service.
- ▶ Do not use trucks with an incomplete or faulty fork extension lock. Replace the fork extension.
- ▶ Only restore the fork extension to service when the fault has been rectified.
- ► Use only fork extensions which have no dirt or foreign bodies near the entry opening point. Clean the fork extensions as required.

4.13 Operating additional attachments for the SOLO-PILOT

⚠ WARNING!

Incorrect symbols can cause accidents

Symbols on controls that do not depict the function of the attachments can cause accidents.

- ► Mark the controls with symbols that indicate their function.
- ▶ Specify the attachments' direction of movement in accordance with ISO 3691-1 so that they match the controls' direction of movement.

4.13.1 Solo Pilot with control of ZH1 hydraulic port

Depending on the attachments used the lever (119) is assigned the function of the attachment. Levers that are not required are void. For connections (see "Fitting additional attachments" on page 91).

Procedure

Operating the hydraulic port ZH1:
 Move the lever (119) in direction V or R.
 The attachment's function is performed.




4.13.2 Solo Pilot with control of ZH1 and ZH2 hydraulic ports

Depending on the attachments used the lever / button (119, 121, 120) is assigned the function of the attachment. Levers that are not required are void. For connections (see "Fitting additional attachments" on page 91).

Procedure

- Operating the hydraulic port ZH1:
 Move the lever (119) in direction V or R.
- Operating the hydraulic port ZH2:
 Press the toggle switch (120) and at the same time move the lever (121) in the V or R direction.

The attachment's function is performed.




4.13.3 Solo Pilot with control of ZH1, ZH2 and ZH3 hydraulic ports

Functions are assigned to the levers / buttons (119, 121, 120) depending on the attachments used. Levers that are not required are void. For connections (see "Fitting additional attachments" on page 91).

Procedure

- Operating the hydraulic port ZH1:
 Move the lever (119) in direction V or R.
- Operating the hydraulic port ZH2:
 Move the lever (121) in direction V or R.
- Operating the hydraulic port ZH3:
 Press the toggle switch (120) and at the same time move the lever (121) in the V or R direction.

The attachment's function is performed.



4.14 Fitting additional attachments

↑ WARNING!

Incorrectly connected attachments can cause accidents.

Attachments with incorrectly connected hydraulic attachments can result in accidents.

- ► Attachments must only be assembled and commissioned by trained, specialist personnel.
- ▶ Note the attachment manufacturer's operating instructions.
- ▶ Before commissioning, check the fasteners are positioned correctly and securely and make sure they are complete.
- ▶ Before commissioning, make sure the attachment is working correctly.

Hydraulic ports

Requirements

- Non-pressurised hydraulic hoses.
- The exchange ports on the truck are marked ZH2 and ZH3.
- Attachment directions of movement defined to match the controls' direction of movement.

Procedure


- Lower the fork carriage to the ground.
- Turn off the ignition (set the ignition / starter switch 0).
- Turn the ignition on again (set the ignition / starter switch I), but do not start the motor.
- Move all levers as far as they will go in both directions several times. The driver's seat must be occupied to do this. Otherwise the control lever will remain in neutral
- Attach the plug connector and engage it in position.
- Mark the controls with symbols that indicate their function.

The attachment is now hydraulically connected.

↑ WARNING!

Hydraulic ports for clamping attachments

- ► Clamping attachments may only be added to trucks which have a button to enable additional hydraulic functions.
- ▶On trucks with auxiliary hydraulics ZH2 the clamping function should only be attached to the coupling pair marked ZH2.
- ▶On trucks with auxiliary hydraulics ZH3 the clamping function should only be attached to the coupling pair marked ZH3.



Spilled hydraulic oil must be set using a suitable agent and disposed of in accordance with environmental regulations.

If hydraulic oil comes into contact with the skin, wash it off immediately with soap and water. If it comes into contact with the eyes rinse them immediately with flowing water and call for a doctor.

5 Towing trailers

△ DANGER!

Inappropriate speeds and excessive trailer loads can be dangerous

If you do not adapt your speed and / or use an excessive trailer load, the truck can pull apart when cornering and braking.

- ▶ The truck should only be used occasionally to tow trailers.
- ► The overall weight of the trailer should not exceed the capacity indicated on the capacity plate, (see "Identification points and data plates" on page 30). If a load is also transported on the forks, the trailer load must be reduced by the same amount.
- ▶ Do not exceed the maximum speed of 5 km/h km/h.
- ► A truck must not be continually operated with trailers.
- ▶ Do not use supporting loads.
- ▶ Towing must only be performed on level, secure travel routes.
- ► The owner must test trailer operation with the permissible tow load by means of a trial run under the applicable operating conditions on site.

Attaching the trailer

CAUTION!

Trapping hazard

There is a trapping risk when you attach a trailer.

- ▶ Follow the instructions of the coupling manufacturer if using special trailer couplings.
- ➤ Secure the trailer to prevent it from rolling away before coupling it. ➤ Do not get caught between the truck and the tiller when coupling the trailer.
- ▶ The tiller must be horizontal, tilted down by no more than 10° and never facing up.

Attaching the trailer


Requirements

- Truck and trailer are on a level surface.
- Trailer prevented from rolling away.

Procedure

- Push the tow pin (123) down and turn it
- Pull the tow pin up and insert the tiller of the trailer into the opening.
- Insert the tow pin, push it down, turn it 90 degrees and engage it.

The trailer is now attached to the truck.



|→|

To additionally ensure safe operation, the truck can be fitted with an electrical connection for trailers with lighting.

6 Optional equipment

6.1 Steel cab

For trucks fitted with a steel cabin, both doors can be closed.

∧ c

CAUTION!


An open door can cause accidents (124)

- ▶ Do not travel with an open door (124). When opening the door make sure there is nobody in the door's swing range.
- ► Always close the door tightly and make sure it is locked.
- Closing the door does not release the driver from his responsibility to wear a seat belt, (see "Seat Belt" on page 65).

Opening and closing the door

Procedure

- To unlock the cabin door turn the key anticlockwise.
- To lock the cabin door turn the key clockwise.
- To open the cabin door, unlock the door and pull out the handle (125).



6.2 Sliding windows

\triangle


CAUTION!

An unlocked sliding window can cause accidents

► The sliding windows must be locked at all times.

Opening and closing the windows

- Push the lock (126) up.
- Move the window forward or back.
- Insert the lock in the stop (127).



6.3 Panel door

A

CAUTION!

An open door can cause accidents (124)

- ▶ Do not travel with an open door (124). When opening the door make sure there is nobody in the door's swing range.
- ► Always close the door tightly and make sure it is locked.
- ► Closing the door does not release the driver from his responsibility to wear a seat belt, (see "Seat Belt" on page 65).

Hazardous situations


If the truck is about to tip over, do not loosen the seat belt. The driver must not jump off the truck. The driver must lean his upper body over the steering wheel and hold on with both hands. Tilt your body in the opposite direction of fall.

Requirements

Rotryckawitea when menitariep och serctosed
 (0).

Procedure

- Pull the handle (128) towards the operator position, the door swings open.
- Pull the door (124) towards the driver; the door closes.



6.4 Backrest extension

A

CAUTION!

Accident risk when adjusting the backrest during travel

► The backrest extension must not be changed during travel!


- The backrest extension height can be adjusted by changing the detent.
- To do this push the backrest up or down.

6.5 Heating


Replacing the air conditioning filter

Procedure

- Unscrew the cover (129).
- Clean the inside of the filter mat or replace it if necessary.



Check the filter after 500 operating hours and replace it at the latest after 1000 operating hours.



Item	Name	Item	Name
130	Windscreen jets		Recirculating air flap:
			Recycling the air in the cab
121	Fan cottings	13/	Heating console
132	Temperature controller	135	Foot compartment jet

https://www.besttruckmanuals.com/

Heating operation

- Press the switch (131) to switch off the fan.
- Set the nozzles (135 and 130) to the required position.
- Turn the temperature controller (132) to the right to increase the cab temperature.
- Turn the temperature controller (132) to the left to decrease the cab temperature.
- The recirculating air flap (133) on the heating console (134) is used to make cab air settings and adjust fresh air.

6.6 Removable load backrest

↑ CAUTION!


Trapping hazard and heavy load backrest weight

- ▶ Wear safety gloves and safety shoes when carrying out this operation.
- Two people are required to remove and attach the load backrest.

Load backrest disassembly

Procedure

- Loosen the screws (136)
- Remove the load backrest from the fork carriage and put it down securely.



Load backrest assembly


Procedure

- Attach the load backrest to the top rail of the fork carriage.
- Fit the bolts and tighten them with a torque wrench.

→ Torque = 85 Nm

6.7 Fire extinguisher

- Open the fasteners (137)
- Pull the fire extinguish out of its bracket To operate, refer to the illustrations on the fire extinguisher




6.8 Rockinger coupling with hand lever or remote control


Refer to the instructions for towing trailers, (see "Towing trailers" on page 93).



Incorrectly coupled trailers can cause accidents

- ► Make sure the coupling is engaged securely before starting the truck.
- ► The contro pin (141) must be flush with the control sleeve (140).





Procedure

- Prevent the trailer from rolling away.
- Adjusting the trailer pull rod to the height of the coupling.
- Pull the hand lever (138) / remote control (139) (○) up.
- The remote control (139) (○) is located in the overhead guard, depending on the truck model.
 - Slowly reverse the truck until the coupling engages.
 - Push the hand lever (138) / remote control (139) (○) down.

Rockinger coupling operation (disconnecting trailers)


- Prevent the trailer from rolling away.
- Pull the hand lever (138) / remote control (139) (○) up.
- Drive the truck forward.
- Push the hand lever (138) / remote control (139) (○) down.

6.9 Camera system

↑ CAUTION!

Accident risk from hidden work areas

- ▶ The camera system acts as an aid to assist safe operation.
- ▶ Practice travelling and working with the camera system.
- ▶ Align the camera so that the hidden work area can be seen.
- When using the camera to reverse, the monitor automatically switches on when you engage reverse gear.



Using the camera system

- Press the button (142) on the monitor to switch the camera system on or off.
- Press the button (143) to lighten or darken the screen (day / night settings).
- Press the button (146) to open the menu.
- Pressing the button several times changes the menu item (contrast, brightness, colour saturation, language, video, light reflection) or quits the menu.

Adjusting the menu items

- Press the button (144) to go one step forward.
- Press the button (145) to go one step back.
- Clean a dirty screen or vent slots with a soft cloth or brush.

6.10 Optional equipment for working in areas with heavy accumulation of dust

When working in areas with high levels of dust (lint, splinters) the Industrial truck can be fitted with an optional lint filter on the cooler.

A


CAUTION!


Clogged lint filters can cause fires

▶ The lint filter must be cleaned regularly according to how much it is clogged.

Procedure

- Remove the cover (147) after the lock (148) is opened.
- Remove the (149) lint mesh and clean it.
- Fit the lint mesh back and set the cover in place.






6.11 Tilt angle display

NOTE

The current tilt angle is shown in an additional display that is attached on the right of the dashboard.

 Green LEDs (150) indicate the vertical position to the ground.



6.12 Speed reduction

The maximal achievable speed is limited to a preset value. Full motor speed and power are available while stopped and accelerating. The speed of the motor is not ramped down until the set maximum speed is reached.

The maximum speed is factory set and can be adjusted by trained and authorised customer service personnel.

6.13 Transmission block

The gear block is an option which prevents the driver from starting the truck if it is in gear. The block also prevents the driver from changing the direction of travel when the truck is in second gear.

 \rightarrow Important: although the truck can travel when shifting gear in idle, braking is still enabled.

6.14 Reversing Block

The travel direction can only be changed (reversing) if the industrial truck is travelling at less than 3 km/h. If the driver attempts to change direction without braking at a faster speed, the system automatically activates idle speed. The required travel level can only be applied when the speed is reduced accordingly.


The drive cannot be set from neutral to travel if the engine is more than 300 rpm above idle speed. Travel is only activated when the speed falls below this limit.

6.15 Direction switch mounted to the steering column

The travel direction switch is attached to the steering column on the left

When the travel direction switch is in the centre position, the drive is in idle / neutral

- Procedure
 To select forward gear, push the lever
- To select reverse gear, push the lever back.



Travel is released in the same way as for the standard version ((see "Travel" in chapter 4.5)).

6.16 Temperature control system


A

WARNING!

In each case the cause of the overheating must be established and rectified by a trained and authorised customer service engineer.

The warning indicator (79) goes on and an audible warning is sounded when the permissible coolant temperature is exceeded. The truck will only travel for another 30 seconds, after which the drive is automatically switched to neutral.

As soon as the permissible coolant temperature is exceeded, proceed as follows:



- Remove the truck from the hazardous area if necessary,
- Lower the fork carriage and load securely.
- Switch the drive to neutral and apply the parking brake.
 Run the motor at a slightly higher speed (to improve the cooling effect of the fan) until the temperature drops back to the normal level.
- If the temperature does not drop, park the truck securely, switch the motor off and have the truck examined.
- In acutely hazardous situations, after the 30 second residual travel period, the truck can be operated again for a further 30 seconds by switching off the ignition and starting the engine again.

6.17 Control layout with Cardan function


∧ w

WARNING!

Ensure there are no other people standing underneath the raised load and driver's cab.

- ▶ Do not stand on the load handler.
- ▶ Do not lift other people on the load handler.
- ▶ Instruct other people to move out of the hazardous area of the industrial truck.
- ▶ Never stand underneath a raised and unsecured load handler / driver's cab.

- Push the main control lever (151) forward to tilt the mast forward.
- Push the main control lever to the right and forward to tilt the mast forward and raise the load.
- Push the main control lever to the right to raise the load.
- Push the main control lever to the right and pull back to tilt the mast back and raise the load.
- Pull the main control lever back to tilt the mast back.
- Pull the main control lever back and push to the left to tilt the mast back and lower the load.
- Push the main control lever to the left to lower the load.
- Push the main control lever to the left and forward to tilt the mast forward and lower the load.



7 Troubleshooting

7.1 Troubleshooting

This chapter enables the user to identify and rectify basic faults and the effects of incorrect operation. When trying to locate a fault, proceed in the order shown in the table.

If, after carrying out the following remedial action, the truck cannot be restored to operation or if a fault in the electronics system is displayed with a corresponding error code, contact the manufacturer's service department. Additional troubleshooting must only be performed by the manufacturer's specialist service engineers. The manufacturer's customer service department is specially trained to carry out these operations.


In order for customer services to react quickly and specifically to the fault, the following information is essential:

- Truck serial number
- Error number on the display unit (if applicable)
- Error description
- Current location of truck

Operational fault displays

Faults during operation are indicated by indicators being lit:

- Engine oil pressure (83)
- Charge current (91)
- Coolant temperature (79)
- Transformer temperature (85)



MARNING!

Risk from engine damage

- The engine must be switched to industrial truck should be parked securely.
- ► Contact the manufacturer's service department.
- ► The engine should only be started again once the fault has been removed.
- Check the fuel display (64) during operation (with TFG option).

Fault	Possible Cause	Action
Starter does not turn	Travel direction switch not in neutral	Set the travel direction switch to neutral.
	Battery charge too low	Check battery charge, charge battery if necessary
	Battery terminal cable loose or terminals oxidized.	Clean and grease terminals, tighten battery terminal cable
	Starter cable loose or broken	Check the starter motor cable
Engine does not start	Air filter contaminated	Clean / replace air filter
	Additional for LPG	
	LPG bottle shutoff valve closed	Shutoff valve open
	LPG bottle empty	Replace the LPG bottle
	Ignition distributor cap	Ignition distributor cap dry, if necessary apply
	damp Spark plugs damp, oily or loose	contact spray Dry, clean and tighten spark plugs
	Spark plugs faulty	Replacing spark plugs
	Additional for diesel	
	Fuel tank empty, injection system has drawn in air	Fill up with diesel and bleed the injection system
	Water in fuel system	Discharge the fuel system Fill up the truck Bleeding the fuel system
	Fuel filter contaminated	Check the flow of fuel, if necessary replace the fuel filter
	Paraffin separation from the diesel (flakes forming)	Park the truck in a warm room and wait until the separation has returned to its original state. If necessary replace the fuel filter Filling with winter diesel
Engine oil indicator lit during operation	Engine oil level too low	Check engine oil level, top up if necessary

Fault	Possible Cause	Action	
Engine	Engine oil level too low	Check engine oil level, top up if necessary	
temperature	Radiator contaminated	Clean radiator	
display in red zone	Coolant level too low	Check engine radiator system for leaks, add coolant if necessary	
	Fan V belt slipping	Check V belt tension, tighten or replace as required	
	Transmission oil level	Check transmission oil level, top up if necessary	
during operation	Radiator contaminated	Clean radiator	
	Travel direction switch in neutral	Set travel direction switch to required direction	
truck does not travel	Parking brake applied	Releasing the parking brake	
Truck does not reach max. speed	Transmission oil level too low	Check transmission oil level, top up if necessary	
Lift speed too low	Hydraulic reservoir oil level too low	Check hydraulic oil, top up if necessary	
	Hydraulic reservoir discharge system contaminated or blocked	Clean / replace hydraulic reservoir discharge system	
Excessive steering play	Air in steering system	Check hydraulic oil level and top up if necessary, then turn the steering wheel several times from one end to the other.	
Malfunction in the electrical system	Faulty fuse	Test fuses (see chapter F)	

7.2 Operating the truck without its own drive system

7.2.1 Towing the truck

↑ WARNING!

Accident risk

Other people can be injured if the truck is towed incorrectly.

- ▶ Only use vehicles to tow the truck which have sufficient tow and brake forces for the trailer load without its own braking system.
- ► Always use a pull rod to tow.
- ► Always tow the truck at walking pace.
- ▶ Do not park the truck with the parking brake released.
- ▶ One person must be seated in the recovery truck to steer it and one person must be seated on the towed truck.

Towing the truck


Requirements

Park the truck securely.

Procedure

- Connect the pull rod to the trailer coupling (44) of the towing truck and attach it to the truck to be towed.
- Release the parking brake, (see "Parking brake" on page 76).
- Tow the truck to its destination.
- Apply the parking brake, (see "Parking brake" on page 76).
- Undo the tow connection.

The truck has now reached its destination.



7.2.2 Emergency lowering

The mast can be lowered manually if a fault occurs in the hydraulic system.

WARNING!


Lowering the mast can result in injuries

- ▶Instruct other people to move out of the hazardous area of the truck during emergency lowering.
- Never stand underneath a raised load handler.
 Only operate the emergency lowering valve when standing next to the truck.
- ▶ Emergency lowering of the mast cannot be applied when the load handler is in the rack.
- ▶ Report any defects immediately to your supervisor.
- ► Tag out and decommission a faulty lift truck.
- ▶ Only return the truck to service when you have identified and rectified the fault.

Procedure

- Press the Emergency Disconnect switch.
- Turn key switch to "0".
- Apply the parking brake.Open the engine cover.
- Pull the protective cover off the left valve.
- Push the locking pin (152) on the valve block forward, thereby releasing the control lever.
- Lower the mast with the lever.

The mast is now lowered.



152

WARNING!

Only return the truck to service when you have identified and rectified the fault.

7.2.3 Starting aid





WARNING!

Danger from overheating

► Only use an ISO 6722 battery jump lead with fully insulated terminal pliers and a lead diameter of at least 25 mm².

- First connect the positive terminal of the feeder battery to the positive terminal with the red lead.
- Connect the negative terminal of the feeder battery to the negative terminal with the black lead.
- To start the truck switch on the ignition with the engine cover open.
- Start the engine as normal.
- When the engine has started first remove the negative lead followed by the positive lead





F Industrial Truck Maintenance

1 Operational Safety and Environmental Protection

The checks and servicing operations contained in this chapter must be performed in accordance with the intervals as indicated in the servicing checklists.

WARNING!

Risk of accidents and damage to components

Any modification to the truck, in particular the safety mechanisms, is prohibited. Do not alter the truck's operating speeds under any circumstances. Do not bond the front window with adhesive.

Exception: Owners should only make changes or have changes made to powered industrial trucks if the truck manufacturer is no longer operating in the field and there is no successor to the business; owners must however:

- Ensure that the changes to be made are planned, tested and performed by a specialist engineer in industrial trucks taking safety into account.
- keep permanent graphic records of the plans, tests and completion of the changes
- carry out and have authorised the respective changes to the capacity data plates, decals and stickers as well as the operator and service manuals.
- attach permanent and clearly visible marking to the truck indicating the types of changes made, the date of the changes and the name and address of the organisation responsible for the work.

NOTE

Only original spare parts have been certified by our quality assurance department. To ensure safe and reliable operation of the truck, use only the manufacturer's spare parts.

For safety reasons, only components which have been specially agreed by the manufacturer for this truck may be installed near the computer, controllers and wire guidance sensors (antennae). These components (computers, controllers, wire guidance sensors (antennae)) must therefore not be replaced either by similar components from other trucks of the same series.



On completion of inspection and service work, carry out the operations listed in the "Recommissioning the truck after cleaning or maintenance work" section ((see "Restoring the truck to service after maintenance and repairs" on page 160)).

2 Maintenance Safety Regulations

Maintenance and repair personnel

Truck maintenance and repair work must only be carried out by specially trained personnel. A maintenance contract with the manufacturer will ensure trouble-free operation. The manufacturer's service department has customer service technicians specially trained for these tasks.

Lifting and jacking up

A

WARNING!

Lifting and jacking up the truck safely

In order to raise the truck, the lifting gear must only be secured to the points specially provided for this purpose.

You may only work under a raised load handler / raised cab if they have been secured with a sufficiently strong chain or the fastening bolt.

In order to raise and jack up the truck safely, proceed as follows:

- ▶ Jack up the truck only on a level surface and prevent it from moving accidentally.
- ► Always use a jack with sufficient capacity. When jacking up the truck, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks).
- ▶In order to raise the truck, the lifting gear must only be secured to the points specially provided for this purpose, (see "Identification points and data plates" on page 30).
- ► When jacking up the truck, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks).

Cleaning



CAUTION!

Fire hazard

The truck must not be cleaned with flammable fluids.

If flammable materials are not removed from the engine compartment, they can come into contact with hot components and cause a fire.

- ► Carry out all necessary safety measures to prevent sparking before cleaning (e.g. by short-circuiting).
- ▶ Remove all deposits / accumulations of flammable materials from the engine compartment.



CAUTION!

Risk of electrical system damage

The electrical system can be damaged if it is cleaning with water. It is prohibited to clean the electrical system with water.

- ▶ Do not clean the electrical system with water.
- ► Clean the electrical system with weak suction or compressed air (use a compressor

with a water trap) and not a conductive, anti-static brush.



CAUTION!

Risk of component damage when cleaning the truck

If the truck is to be cleaned with a water jet or a high-pressure cleaner, all electrical and electronic components must be carefully covered beforehand as moisture can cause malfunctions. Do not clean with pressurised water.



After cleaning, carry out the operations detailed in "Recommissioning the truck after cleaning or maintenance work" ((see "Restoring the truck to service after maintenance and repairs" on page 160)).

Electrical system

Λ

CAUTION!

Accident risk from Electrical system:

- ▶ Only trained personnel may work on the electrical system.
- ▶ Before working on the electrical system, all precautionary measures must be taken to avoid electrical accidents.
- ▶The connecting leads on the starter battery must be disassembled to disable it.



WARNING!

Electric currents can cause accidents

Make sure the electrical system is voltage-free before starting work on it. Before starting maintenance on the electrical system:

- ▶ Park the truck securely ((see "Parking the truck securely" on page 71)).
- ▶ Press the Emergency Disconnect.
- ▶ Disconnect the battery.
- ▶ Remove any rings or metal bracelets etc. before working on electrical components.

Consumables and used parts



CAUTION!

Consumables and used parts are an environmental hazard

Used parts, oils and fuels must be disposed of in accordance with the relevant environmental protection regulations. To change the oil contact the manufacturer's customer service department, who have been specially trained for this task.

▶ Note the safety regulations when handling these materials.

Welding

Remove electrical and electronic components from the truck before performing welding operations, to avoid damage.

Settings

When repairing or replacing hydraulic, electric or electronic components or assemblies, always note the truck-specific settings.

Tyre type



WARNING!

The use of tyres that do not match the manufacturer's specifications can result in accidents.

The quality of tyres affects the stability and performance of the truck.

Uneven wear affects the truck's stability and increases the stopping distance.

- ▶When replacing tyres make sure the truck is not skewed.
- ► Always replace tyres in pairs, i.e. left and right at the same time.
- **→**

When replacing rims and tyres fitted at the factory, only use the manufacturer's original spare parts. Otherwise the manufacturer's specifications cannot be ensured.

Lift chains



WARNING!

Non-lubricated and incorrectly cleaned lift chains can cause accidents

Lift chains are safety-critical parts. They must not contain any serious contamination.

- Lift chains and pivot pins must always be clean and well lubricated.

 Lift chains should only be cleaned with paraffin derivatives e.g. petroleum or diesel fuels.
- ► Never clean lifting chains with steam jet high pressure cleaners or chemical cleaning agents.
- Immediately after cleaning, dry the lift chain with compressed air and apply a chain spray.
- ► Always lubricate a chain when it is discharged.
- Lubricate a lift chain with particular care around the pulleys.

A

WARNING!

- Diesel fuel can be hazardous into contact with the skin. Rinse any affected areas thoroughly.
- If it comes into contact with the eyes rinse them immediately with flowing water and call for a doctor.
- ►Wear safety gloves when handling diesel fuels.

Hydraulic hoses



WARNING!

Brittle hydraulic hose lines can cause accidents

The hoses must be replaced every six years. The manufacturer's customer service department is specially trained to carry out these operations.

A

WARNING!

Hydraulic line leaks can cause accidents

Hydraulic oil can escape from leaky and faulty hydraulic lines.

- ▶ Report any defects immediately to your supervisor.
- ► Tag out and decommission a faulty lift truck.
- ▶ Only return the truck to service when you have identified and rectified the fault.
- ➤ Spilled fluids must be removed immediately with an appropriate bonding agent. The bonding agent / consumable mixture must be disposed of in accordance with regulations.



WARNING!

Hairline cracks in the hydraulic lines can cause injury and infection

Pressurised hydraulic oil can penetrate the skin through fine holes or hairline cracks in the hydraulic lines, causing severe injury.

- ► Call for a doctor immediately if you are injured.
- ▶ Do not touch pressurised hydraulic lines.
- ▶ Report any defects immediately to your supervisor.
- ► Tag out and decommission a faulty lift truck.
- ▶ Only return the truck to service when you have identified and rectified the fault.
- ▶ Spilled fluids must be removed immediately with an appropriate bonding agent. The bonding agent / consumable mixture must be disposed of in accordance with regulations.



WARNING!

Danger from hot fluids and components!

- ► Consumables (hydraulic oil, engine oil, coolant) and power train components (engine, manifold, exhaust system, turbo charger etc.) get very hot during operation.
- ► When carrying out maintenance and repairs wear suitable protective clothing (gloves etc.) to avoid getting burned.

3 Servicing and Inspection

Thorough and expert servicing is one of the most important requirements for the safe operation of the industrial truck. Failure to perform regular servicing can lead to truck failure and poses a potential hazard to personnel and equipment.

A

WARNING!

The application conditions of an industrial truck have a considerable impact on the wear of the service components.

We recommend that a Jungheinrich customer service adviser carries out an application analysis on site to work out specific service intervals to prevent damage due to wear.

The service intervals stated are based on single shift operation under normal operating conditions. They must be reduced accordingly if the truck is to be used in conditions of extreme dust, temperature fluctuations or multiple shifts.

The following servicing checklist indicates the operations to be performed and the respective intervals to be observed. Maintenance intervals are defined as:

W = Every 50 service hours, at least weekly

A = Every 500 service hours

B = Every 1000 service hours, or at least annually

C = Every 2000 service hours, or at least annually

= Standard maintenance interval

* = Cold store maintenance interval (in addition to standard maintenance interval)

W maintenance intervals must be performed by the owner.

During the run-in period – after approx. 100 service hours – the owner must check the wheel nuts / bolts and re-tighten if necessary.

4 Maintenance checklist

DFG / TFG

		Maintenance intervals				2
		Standard = •	W	Α	В	С
Chas	sis / Superstructure		- 12 1		2 - 25	
1.1	Check all load bearing components for damage.					
1.2	Check screw connection.				. 3	
1.3	Check overhead guard for damage	e and make sure it is secure.				
1.4	Check trailer hitch.		8			
1.5	Check the engine compartment fo necessary.	r contamination and clean if	•		<i>3</i> - 23	

		Service intervals				ĵ
06		Standard = •	W	Α	В	С
Drive			2			
2.1	Combustion engine, see separate	checklist				6
2:3	Check the transmission for noise and leakage Check pedal mechanism, adjust and lubricate if necessary			•		
2.4	Check the gear oil level					- 20
2.5	Change the gear oil					
2.6	Clean gear oil suction filter and dis	scharge				
2.7	Changing the gear oil filter					•
2.8	Check drive axle for noise and lea	kage				
2.9	Check drive axle oil level (hydrokir	netic only)		•		
2.10	Replace drive axle oil (hydrokinetic	c only)				
2.11	Check switching mechanism on co the contact surfaces (hydrokinetic					
2.12	Lubricate drive axle / mast swivel	axle (hydrokinetic only)				Ĵ

		Service intervals				
		Standard = •	W	Α	В	C
Brake	e system		63			
3.1	Test operation and settings					
3.2	Check brake lining wear (hydrokinetic only)			•	0 0	
3.3	Check brake mechanism, adjust and lubricate if necessary (hydrokinetic only)			•		
3.4	Check brake lines, connections ar only)	nd brake fluid level (hydrokinetic		•		
3.5	Change brake fluid (hydrokinetic o	only)				•

		Service intervals	4.5			
		Standard =	W	Α	В	С
Whee	els				•	
4.1	Check wheels for wear and dam	age				
4.2	Check suspension and fastening		2	•	S. :	
4.3	Check air pressure		•			

	Maintenance inte	Maintenance intervals				
	Standard = •	8	W	Α	В	С
Steer	ring	6)		je j	to	
5.1	Check the steering play.					
5.2	Check the mechanical parts of the steering column; g necessary.	rease if		•		
5.3	Check the steer axle, stub axle, stops for wear and de	eformation.			3-73	
5.4	Test the operation of the hydraulic components and c	heck for leaks.				
5.5	Grease the steering axle.	3				- 3

		Maintenance intervals				
63		Standard = •	W	Α	В	С
Mast				0	m	
6.1	Check mast attachment.					
6.2	Check and lubricate the mast susp	pension.		•		
6.3	Check operation, wear and setting	J.				
6.4	Visually inspect rollers, slide piece	es and stops.				
6.5	Check lift chains and guides for w	ear, adjust and lubricate.				
6.6	Check lateral slack and ensure ma	ast sections are parallel.				
6.7	Check fork tines and fork carriage	for wear and damage.				
6.8	Sherk protective mechanisms for	damage and make sure they are		•		
6.9	Check the tilt cylinder suspension	and fastening.				
6.10	Check the mast tilt angle.					
6.11	Check the running surfaces of the lubricate if necessary.	mast for wear and damage, and			= 8:	

	Serv	ice intervals				
	Stan	dard = •	W	Α	В	С
Hydra	aulic system				50 - SO	
7.1	Test operation				, s	
7.2	Check connections and ports for leaks a	and damage				
7.3	Check hydraulic cylinder for leaks and damage and make sure it is secure			•		
7.4	Check oil level					
7.5	Replace hydraulic oil					
7.6	Replace filter cartridge				•	
7.7	Clean hydraulic oil suction filter and disc	charge				
7.8	Test operation of pressure limitation val-	/es				
7.9	Test hose guide and check for damage			•		

	Service inte	rvals		200	
	Standard =	W	Α	В	C
Elect	trical system	•			
0.4		3	•	6. 68	
8:2	Make sure wire connections are secure and che	ck for damage	•		
			•		
8.4	Test operation of instruments and displays		•		

	Service intervals				
	Standard = •	W	Α	В	С
Batte	ery				
9.1	Check acid density, acid level and battery voltage		•	G 8	
9.2	Check terminals are securely attached, and apply terminal so grease	rew	•		
9.3	Check battery cables for damage, replace if necessary.	55	•	0 G	

	Service	Service intervals				
	Standar	d = •	W	Α	В	С
Attac	chment				610 - 181 60 20	
10.1	Test operation					
10.2	Check attachment on truck and load bearing	g components		•		
10.3	Check position of bearings, guides and stops for wear and damage, grease these components.			•	5 - 5	

	Service intervals				
	Standard =	w	Α	В	С
Lubrication https://ww	ww.besttruckmanuals.com/	160	8	S	
	'0 I I ' C O I I I				

122

		Service intervals				
		Standard = •	W	/ A	В	C
Gene	ral measurements	<u> </u>		300	80 0	
12.1	Test travel speed and braking dist	ance				
12.2	Test lift and lowering speeds					•
12.3	Test safety devices and cutouts		¥3:	•	1	

	Servi	Service intervals					
	Stand	dard = •	W	Α	В	С	
Demonstration							
13.1 Test run with rated load					9		
13.2	After carrying out maintenance, present the truck to the supervisor.						

DFG maintenance

		Service intervals	115			
		Standard = •	W	Α	В	C
Engi	ne			•		
1.1	Check engine for noise and leaks		-3	•	6) (6	
1.2	Check injection pump flow start, a	djust if necessary			St 10	•
1.3	Check injector pressure, adjust if	necessary		•		
1.4	Tighten cheese head screws					•
1.5	Check valve play, adjust if necess	ary		•		
1.6	Check engine oil level, top up if necessary					
1.7	Replace the engine oil.		- 64	•		
1.8	1.8 Replace the engine oil filter					
1.9	1.9 Check V belt for tension and damage					
1.10 Check maximum speed (without load), adjust if necessary		oad), adjust if necessary		•		
		Service intervals				
		•		Î		
Cool	ant	Standard =	W	A	В	С
8	Check the coolant level and top up	p if required (change coolant	Τ_			
2.1	annually)	p in rodaine a (enamge coeraine				
2.2	Check anti-freeze content, top up	if necessary				•
	•				O	
		Service intervals				
		Standard = •	w	Α	В	С
Exha		Guilladia			9 9	
3.1	Check exhaust system for leaks a	nd damage	Т			
3.2	Check exhaust levels, adjust if ne		-		-	
0.2	Officer extrades levels, adjust if the					
		Service intervals	1,,,,			
		Standard = •	W	A	В	С
Air fi			-4			
4.1	Clean air filter cartridge		-	•		
4.2	Replace air filter cartridge					
		Service intervals	112			
		Standard = •	w	Α	В	C
Hydr	aulics		-			
5.1	Check and lubricate the hydraulic	pump drive	-3	•	6) 6	

	Service intervals	Service intervals				
	Standard =	W	Α	В	C	
Fuel	system					
6.1	Replacing the fuel filter			a		
6.2	Check fuel/water separator, and discharge if necessary		•			
6.3	Check fuel tank and lines for leaks and damage		•	2-3		

TFG maintenance

		Service intervals				
		Standard = •	W	Α	В	С
Engi	ne					
1.1	Check engine for noise and leaks		3 3		(S)	
1.2	Check spark plugs, replace if nece	essary		•	d (8	
1.3	Check ignition time, adjust if nece	ssary				
1.4	Check ignition distributor, adjust if necessary					
1.5	Check valve clearance, adjust if necessary					
1.6	Check engine oil level, top up if ne	ecessary	•			
1.7	Replace the engine oil		8 -			
1.8	Replace the engine oil filter					
1.9	Check V belt for tension and dama	age		•		
1.10	Check maximum speed (without lo	oad), adjust if necessary				
-						
		Service intervals				
Cool	ant	Standard =	- W	A	В	-c
2.1	Check the coolant level and top up annually)	p if required (change coolant	•			
2.2	Check anti-freeze content, top up	if necessary				•
	1				0	
		Service intervals				
		Standard = •	W	Α	В	С
Exha	nust	2			5 V)	
3.1	Check exhaust system for leaks a	nd damage				•
3.2	Check exhaust levels, adjust if ne	cessary			5 - 6	•
	·	<u> </u>				
		Service intervals				
		Standard = •	W	Α	В	С
Air fi	lter				=	_
4.1	Clean air filter cartridge					
4.2	Replace air filter cartridge			3		
			(8)		25 - 26	
		Service intervals				
		Standard = •	W	Α	В	С
Hydr	aulics	I.s				
5.1	Check and lubricate the hydraulic	pump drive	28 - 3		0	

	Service intervals	Service intervals				
	Standard = •		W	Α	В	С
LPG	system	_3				
6.1	Check LPG system for leaks and damage				a es	
6.2	Have LPG filter replaced by specialist) (3.————————————————————————————————————	
6.3	Have LPG system examined by specialist				2 13	
6.4	Have the exhaust pollutant levels checked by a specialist and to the lowest level achievable.	adjust			•	
6.5	Check and service Impco units				6 12	

5 Lubricants and Lubrication Schedule

5.1 Handling consumables safely

Handling consumables

Consumables must always be handled correctly. Follow the manufacturer's instructions.

Λ

WARNING!

Improper handling is hazardous to health, life and the environment

Consumables can be flammable.

- ► Keep consumables away from hot components and naked flames.
- ► Always keep consumables in prescribed containers.
- ► Always fill consumables in clean containers.
- ▶ Do not mix up different grades of consumable. The only exception to this is when mixing is expressly stipulated in the operating instructions.



CAUTION!

Riskled sliguids from spilled sliguing and endanger the environment with water.

- ▶ Do not spill fluids.
- ▶ Spilled fluids must be removed immediately with an appropriate bonding agent.
- ► The bonding agent / consumable mixture must be disposed of in accordance with regulations.

A

WARNING!

Oils (chain spray / hydraulic oil) are flammable and poisonous.

- ▶ Dispose of used oils in accordance with regulations. Store used oil safely until it can be disposed of in accordance with regulations.
- ▶ Spilled fluids must be removed immediately with an appropriate bonding agent.
- ► The bonding agent / consumable mixture must be disposed of in accordance with regulations.
- ▶ Observe national regulations when handling oils.
- ►Wear safety gloves when handling oils.
- ▶ Prevent oil from coming into contact with hot motor parts
- ▶ Do not smoke when handling oil.
- Avoid contact and digestion. If you swallow oil do not induce vomiting but call for a doctor immediately.
- ► Seek fresh air after breathing in oil fumes or vapours.
- ▶ If oil has come into contact with your skin, rinse your skin with water.
- ► If oil has come into contact with your eyes, rinse them with water and call for a doctor immediately. https://www.besttruckmanuals.com/
- doctor immediately. https://www.besttruckmanuals.com/
 Replace oil-soaked clothing and shoes immediately.

Consumables and used parts




CAUTION!

Consumables and used parts are an environmental hazard

Used parts, oils and fuels must be disposed of in accordance with the relevant environmental protection regulations. To change the oil contact the manufacturer's customer service department, who have been specially trained for this task.

▶ Note the safety regulations when handling these materials.

5.2 Lubrication Schedule



- ▼ Contact surfaces
- ↓ Grease nipple
- ☼ Hydraulic oil drain plug
- M Coolant expansion vessel
- E Steer axle lubrication
- K Engine oil filler neck

5.3 Consumables

DFG/TFG 540-550

Code	Order no.	Packag e quantit y	Capacity	Description	Used for
A	51132827	51	80 I	Hypebeierish	HysterHlic
D	00002832		0.31	Brake fluid SAE J 1703	Brake System
Е	50055726		V3	K-P-2K grease	
G	29201280	400 ml	E ₂	Chain spray	Mast chains
N	05099205		7.3 l	ATF Dexron II D	Transmission
Р	51050011	20 I	4.5 l	Titan Supergear 80W-90	Axle
K	51094056	51	6.9 I (DFG) 4.7 I (TFG)	Titan UNIC PLUS SAE 10W-40	Engine oil
М	51115303	11	16 l	Fricofin S	Coolant*

^{*} The coolant consists of a 1:1 mixture ratio of Fricofin S and water

The volumes indicated are approximate.

MARNING!

Using incorrect hydraulic oil can be dangerous

▶ Do not use hydraulic oils with a different specification or viscosity and do not mix with additives.

Grease guidelines

Code	Saponification	Dew _@ oint	Workedூசnetr. at	NLG1 class	tempelication c
Е	Lithium	185	265-295	2	-35/+120

Coolant specification

The quality of the coolant used can have a major impact on the efficiency and service life of the cooling circuit. The recommendations listed below are useful for servicing a good cooling circuit with anti-freeze and/or anti-corrosion.

Always use clean, soft water. Do not use distilled water.

△ DANGER!

Anti-freeze is poisonous

- ► Anti-freeze contains ethylene glycol and other components which can result in poisoning if ingested.
- ▶ Ingression into the human body can also result if poisonous quantities come into contact with the skin for long or repeated periods.
- ▶ Note the manufacturer's safety instructions.

The quality of the anti-freeze must be checked at least annually, e.g. at the start of the cold season.

If the correct procedures are not applied, the manufacturer cannot be held liable for frost or corrosion damage.

NOTE

Corrosion damage

► Even if the coolant cannot freeze up due to the application conditions, you must still use anti-freeze. The anti-freeze provides protection against corrosion and raises the boiling point of the coolant.

NOTE

Anti-freeze/water mixture ratio:

- ▶ 1: 1 (anti-freeze to -35°C)
- ► Never mix different types of anti-freeze.


6 Maintenance and repairs

6.1 Preparing the truck for maintenance and repairs

All necessary safety measures must be taken to avoid accidents when carrying out maintenance and repairs. The following preparations must be made:

Procedure

- Park the truck securely, (see "Parking the truck securely" on page 71).
- Fully lower the load handler.
- Remove the key from the key switch (77) to prevent the truck from being switched on accidentally.



Λ

WARNING!

Risk of accidents when working under the load handler, driver's cab and lift truck

- ► When working under a raised load handler, driver's cab or a raised truck, secure them to prevent the truck from from lowering, tipping or sliding away.
- ► When raising the truck, follow the instructions, (see "Lifting the truck by crane" on page 36). When working on the parking brake, prevent the truck from accidentally rolling away (e.g. with wedges).

6.2 Opening the engine cover

Requirements

 For trucks with a closed cab open both cabin doors before lifting the engine cover (○).


Procedure

- Before opening the engine compartment push the steering column as far forward as it will go and push the seat fully back along its guide rails.
- To open the engine compartment fit a suitable instrument (e.g. screwdriver) through the access hole and push it onto the locking device (153) of the engine cover.
- Lift up the engine cover fully. A gas pressure damper keeps the engine cover in the raised position.
- Make sure the engine cover has engaged correctly before operating the truck again.



Closing the engine cover

- Raise the engine cover slightly and push the bottom section (154) of the gas pressure damper in the direction of the arrow as far as it will go against the top part of the gas pressure damper.
- Push the engine cover down and allow it to lock in place. Push the driver's seat back and lock it in place.
- To adjust the seating position and steering wheel position to your requirements, (see "Adjusting the driver's seat" on page 61).



6.3 Checking the wheel attachments.

Λ

WARNING!

Using different tyres can cause accidents

The quality of tyres affects the stability and performance of the truck.

- ▶ The diameter of the wheels must differ by no more than 15 mm.
- ► Always replace tyres in pairs. After replacing the tyres check the wheel nuts are
- secure after 10 service hours.

 Always use tyres of the same make, model and profile.

Checking the wheel attachment

Requirements

 Prepare the truck for maintenance and repairs ((see "Preparing the truck for maintenance and repairs" on page 133)).


Tools and Material Required


Torque wrench

Procedure

• Torque the wheel nuts (155) crosswise with a torque wrench, for torques (see "Tyre type" on page 26).

The wheel attachment is now checked.





6.4 Hydraulic system

Λ

CAUTION!

The hydraulic oil is pressurised during operation and is a hazard to health and to the environment.

- ▶ Do not touch pressurised hydraulic lines.
- ▶ Dispose of used oil in accordance with regulations. Store used oil safely until it can
- be disposed of in accordance with regulations.
- ▶ Spilled fluids must be removed immediately with an appropriate bonding agent.
- ▶ The bonding agent / consumable mixture must be disposed of in accordance with regulations.
- ▶ Observe national regulations when handling hydraulic oil.
- ► Wear safety gloves when handling hydraulic oil.
- ▶ Prevent hydraulic oil from coming into contact with hot motor parts.
- ▶ Do not smoke when handling hydraulic oil.
- ► Avoid contact and digestion. If you swallow oil do not induce vomiting but call for a doctor immediately.
- ► Seek fresh air after breathing in oil fumes or vapours.

- If oil has come into contact with your skin rinse your skin with water and call for a doctor immediately.
- ▶ Replace oil-soaked clothing and shoes immediately.



CAUTION!

Consumables and used parts are an environmental hazard

Used parts, oils and fuels must be disposed of in accordance with the relevant environmental protection regulations. To change the oil contact the manufacturer's customer service department, who have been specially trained for this task.

▶ Note the safety regulations when handling these materials.

6.4.1 Checking the hydraulic oil level

Requirements

- Park the truck on a level surface.
- Start the engine and fully raise and lower the mast once.
- Switch off the engine.

Procedure

- Remove the hydraulic oil dipstick (156) from the hole wipe it with a clean cloth and insert it fully again.
- Remove the hydraulic oil dipstick and check the level of the hydraulic oil.


For cold oil: The oil level should lie between the "Min." and "Max." levels.


For hot oil: The hydraulic oil should lie just above the MAX marking.

- Add hydraulic oil if necessary.
- Repeat the test.
- When the oil level is correct, fully insert the hydraulic oil dipstick (156) again.



- Unscrew the lid (157) of the hydraulic oil filler neck.
- Add hydraulic oil to the MAX mark on the hydraulic oil dipstick.
- Use only approved hydraulic oil (see consumables table).
 - Check the hydraulic oil level with the dipstick and top up as required.
 - · Screw the lid back on.
 - Insert the dipstick back in full.





6.4.3 Replacing the hydraulic oil filter

A

CAUTION!

If the pressure indicator (158) on the hydraulic oil filter is in the red zone, the filter must be replaced immediately.

Procedure

- Loosen the quick release on the strap retainer of the air filter and push the air filter housing to the side.
- Unscrew the lid (159).
- Remove the hydraulic oil filter in the lid.
- Insert a new hydraulic oil filter and screw the lid back on.
- Fasten the air filter in place again.




Collect any spilled hydraulic oil. Dispose of the hydraulic oil and hydraulic oil filter and fuel in accordance with environmental regulations.


6.4.4 Replacing the ventilation/discharge filter

Procedure

- Unscrew the ventilation/discharge filter (160).
- Visually inspect the filter.
- If contaminated insert a new filter.
- Screw the ventilation/discharge filter back on.



Collect any spilled hydraulic oil. Dispose of the hydraulic oil and hydraulic oil filter and fuel in accordance with environmental regulations.



Engine maintenance 6.5

DANGER!

A running engine can be dangerous.

- ▶ There is a high risk of injury when the cover is open and the engine running.
- ▶ Do not reach into moving parts (e.g. fan, belt drive).
- Truck maintenance and repair work must only be carried out by specially trained
- personnel who have been authorised by the owner. There must be nobody present in the danger zone.

6.5.1 DFG engine maintenance

NOTE

Used oil contaminates the environment

▶ Dispose of used oil and used engine oil filters in accordance with environmental regulations.

CAUTION!

Risk of scalding through hot oil.

▶ Wear appropriate safety gloves when replacing the oil and oil filter.

NOTE

When the engine is cold the engine oil can be viscous.

▶ Only change the engine oil when the engine is at operating temperature and the industrial truck is horizontal. Always replace the engine oil and engine oil filter together.


Checking the engine oil level

Requirements

- Park the truck on a level surface (see "Parking the truck securely" on page 71)

Procedure

- Remove the dipstick (161).
- · Wipe the dipstick with a lint-free cloth and put in back fully into the port.
- Remove the dipstick again and check that the oil level is between the MIN and MAX markings.




 If the engine oil level is below the bottom MIN marking, add engine oil as per the consumables list ((spepsymbol) consumables ((

Draining the engine oil

Procedure


- Unscrew the filler cap.
- Thoroughly clean the oil drain plug (162) and around the drain hole.
- · Unscrew the oil drain plug.
- · Collect any oil that emerges.
- · Screw in the oil drain plug with a new seal.



Replace the engine oil filter


ProcedureUndo the oil filter (163) with a filter wrench and manually unscrew it.

- Thoroughly clean the sealing faces of the oil filter flange.
- Apply a thin layer of engine oil to the seal of the new oil filter.
- Hand-tighten the oil filter.



Adding engine oil


- Add fresh engine oil through the filler port (164) in accordance with the consumables table.
- Check the engine oil level with the dipstick (161) and top up if necessary, (see "Consumables" on page 131).
- · Screw the filler cap back on.



NOTE

The incorrect amount of oil will damage the engine.

- ► After replacing the oil and oil filter carry out a test run and check the oil pressure display (83).
- ► Check that the oil drain plug and oil filter housing are tight.



6.5.2 Replacing the fuel filter


NOTE

Fuel can cause environmental damage

- ► Bind any spilled diesel fuel with suitable methods.
- ► Then dispose of the diesel and fuel filter in accordance with environmental regulations.

Procedure

- Drain the fuel from the filter into a suitable container.
- Undo the filter housing with a filter wrench and manually unscrew it.
- Turn the filter insert anticlockwise to loosen and remove it.
- Install a new filter insert and lock it in place.
- Thoroughly clean the sealing faces of the filter flange.
- Apply a thin layer of diesel to the seal of the new fuel filter (165).
- Prefill the filter housing with clean diesel.
- Screw on the filter housing and handtighten.
- The fuel filter bleeds itself automatically after the ignition is turned on.



→

While running the engine check the fuel filter and the union nuts of the injectors for leaks.

6.5.3 Check V-belt for damage

Procedure

• Check the V-belt for cracks, deformation and wear.

NOTE

A damaged V-belt will result in malfunctions.


▶ If the V-belt is not in a suitable condition, you must only start to use the truck when the damage has been rectified.

6.5.4 Checking the V belt tension

Procedure


 Insert the V belt between the fan V belt pulley (166) and the generator V belt pulley (167) using a force of 45 N.

It should be possible to insert the V belt approx. 10 mm.



6.5.5 Adjusting the V belt tension

- Undo the screws (169) and pull the three-phase alternator (168) until you reach the prescribed V belt tension.
- Re-tighten the screws.
- Check the V belt tension again and repeat the adjustment if necessary.



6.5.6 TFG engine maintenance

NOTE

Used oil contaminates the environment

▶ Dispose of used oil and used engine oil filters in accordance with environmental regulations.



CAUTION!

Risk of scalding through hot oil.

► Wear appropriate safety gloves when replacing the oil and oil filter.

NOTE

When the engine is cold the engine oil can be viscous.

▶ Only change the engine oil when the engine is at operating temperature and the industrial truck is horizontal. Always replace the engine oil and engine oil filter together.

Checking the engine oil level


Requirements

 Park the truck on a level surface (see "Parking the truck securely" on page 71)

Procedure

- Remove the dipstick (161).
- Wipe the dipstick with a lint-free cloth and put in back fully into the port.
- Remove the dipstick again and check that the oil level is between the MIN and MAX markings.
- If the engine oil level is below the bottom MIN marking, add engine oil as per the consumables list ((see "Consumables" on page 131)).


The engine oil has now been checked.



Draining the engine oil


Procedure

- Unscrew the filler cap (164).
- Thoroughly clean the oil drain plug (162) and around the drain hole.
- · Unscrew the oil drain plug.
- Collect any oil that emerges.
- Screw in the oil drain plug with a new seal.




Replace the engine oil filter

- Procedure
 Undo the oil filter (163) with a filter wrench and manually unscrew it.
- Thoroughly clean the sealing faces of the oil filter flange.
- Apply a thin layer of engine oil to the seal of the new oil filter.
- Hand-tighten the oil filter.



Adding engine oil


- Add fresh engine oil through the filler port (164) in accordance with the consumables table.
- Check the engine oil level with the dipstick (161) and top up if necessary, (see "Consumables" on page 131).
- Screw the filler cap back on.



NOTE


The incorrect amount of oil will damage the engine.

- ► After replacing the oil and oil filter carry out a test run and check the oil pressure display (83).
- Check that the oil drain plug and oil filter housing are tight.



6.5.7 Replacing spark plugs

- Remove spark plug connector (170).
- Thoroughly clean around the spark plugs on the cylinder head.
- Unscrew the spark plugs.
- Check the electrode distance of the new spark plugs with a feeler gauge.
- It should be 0.8 mm ± 0.1 mm.
 - Screw in the spark plugs by hand and then torque them to 20 Nm.



6.5.8 Check V-belt for damage

NOTE

A damaged V-belt will result in malfunctions.

▶ If the V-belt is not in a suitable condition, you must only start to use the truck when the damage has been rectified.

Procedure


• Check the V-belt for cracks, deformation and wear.

6.5.9 Checking the V belt tension

The V-belt tension is maintained by an automatic belt tensioner (171). No manual adjustment is required.

Procedure

• If the attachment indicator (172) is outside the index marking, this means a new belt must be fitted.



Λ

CAUTION!

It is essential to route the V-belt correctly.

▶ Belts must be replaced by qualified and authorised personnel.

6.5.10 Cooling system

NOTE

Lack of coolant can cause malfunctions

- ► The coolant level should be between the "MIN" and "MAX" markings on the expansion vessel.
- ▶If the coolant is below the MIN marking, this indicates possible leakage in the radiator system.
- ▶ Do not continue using the truck.
- ▶ The truck may only be started again once the cause has been removed.

Λ

CAUTION!


Hot coolant can cause injury

► Allow the engine to cool down sufficiently to prevent hot gases/liquids from escaping when the filler cap is opened.

Checking the coolant level

Procedure

- Park the truck securely on a level surface.
- Open the engine cover.
- Check the coolant level on the expansion vessel (173).



NOTE

The incorrect coolant can cause malfunctions

- ▶ To prevent the build up of lime as well as front and corrosion damage in the radiator system, and to raise the boiling point temperature of the coolant, the cooling circuit must be filled each year with a mixture of water and anti-freeze with anti-corrosion additives.
- ► Coolant can only be checked and added by experts.

Check the coolant concentrate

Tools and Material Required

- Anti-freeze tester for coolants

Procedure


- Slowly unscrew the filler cap (174) from the expansion vessel (173).
- Check the anti-freeze content of the coolant with an anti-freeze tester.



The incorrect coolant concentration can cause malfunctions

- ► If there is insufficient anti-freeze content arrange for trained personnel to restore the correct mixture ratio.
- · Screw the filler cap back on.
- Close the engine cover.





6.5.11 Replace air filter cartridge

△ DANGER!


A running engine can be dangerous

- ► Carry out all maintenance work with the engine switched off.
- ▶ Do not start the engine if the air filter cartridge is removed.

Replace air filter cartridge

Procedure

- Undo the 2 mounting clamps (176) and remove the dust collector pot.
- Carefully remove the air filter cartridge from the filter housing.



Cleaning the filter housing

Procedure

NOTE

A faulty engine can cause malfunctions

- ▶ Do not clean the air filter housing with compressed air.
- ► Always use a clean cloth to clean the air filter housing.
- Remove the air filter cartridge.
- Thoroughly clean the dust collector pot. To do this remove the dust extraction valve
- Carefully clean the air filter housing with a clean cloth.
- There must be no residue from the cloth in the air filter housing.
- Insert the air filter cartridges back in the filter housing.
- Take care not to damage the air filter cartridges when assembling.
 - Fit the rubber element back into the dust collector pot.
 - Insert the dust collector pot and secure it with the 2 mounting clamps (176).

6.5.12 Adding window washer system fluid

Procedure

- Open the engine cover.
- Make sure there is sufficient windscreen fluid in the container.
- If necessary top up with anti-freeze.
- Fill with weather-dependent additives.

6.6 Checking electrical fuses

Checking electrical fuses

Requirements


- Prepare the truck for maintenance and repairs ((see "Preparing the truck for maintenance and repairs" on page 133)).

Procedure

- Open the engine cover.
 Check condition and rating of the fuses in accordance with the table.
- Replace any damaged fuses in accordance with the table.
- Close the engine cover.

The electrical fuses are now checked.

6.6.1 Fuse ratings



Fuse layout for the basic truck (black fuse box)

Item		Electric circuit	Rating (A)
1		Work lights	20
2	•	Travel direction / reversing light / reversing buzzer	7.5
3	•	Illumination kit A / brake light	20
4	•	Neutral relay / display lighting	7.5
5		Horn / beacon	10
6	Ŏ	Spare	

Fuse layout for cab only (green fuse box)

Item		Electric circuit	Rating (A)
7	0	Heating	15
8	0	Front window wiper	10
9	0	Windscreen washer pump	10
10	0	Rear window heating	15
11	0	Rear window wiper	10
12	0	Radio	10

https://www.besttruckmanuals.com/

●= Series equipment	○= Optional equipment


Fuse box for StVZO illumination only (red fuse box)

Item		Electric circuit	Rating (A)
13	0	Dipped lights	15
14	0	Flasher / parking light	20
15	0	Indicator	15
16	0	Parking light / right tail light	7.5
17	0	Parking light / left tail light	7.5
18	0	Brake light	7.5

Fuse box options 1 (black fuse box)

152


Item		Electric circuit	Rating (A)
19	•	Spare	
20	•	Seat heating	10
21	•	Spare	
22		Spare	
23		Spare	,
24		Spare	2



TFG fuse box

Item		Electric circuit	Rating (A)
25	•	Gas shutoff valve	5
26		Gas shutoff valve	5


https://www.besttruckmanuals.com/
□= Series equipment □= Optional equipment



DFG fuse box

Item	Electric circuit	Rating (A)
27	Pre-heat	100
28	Fuel pump	15

	- Wi-
●= Series equipment	○= Optional equipment



Emergency Disconnect fuse box

Item		Electric circuit	Rating (A)
29		Entire truck	50
30		Seat monitoring	7.5
31	0	Road traffic regulations lighting	30

●= Series equipment	○= Optional equipment
---------------------	-----------------------

⚠ WARNING!

To avoid damaging the electrical system, only use fuses with the correct ratings.

6.7 Starter battery

Checking the battery condition, acid level* and acid density*

*not for maintenance-free batteries

↑ CAUTION!

Battery acid can be dangerous

- ► Battery acid is highly corrosive. Therefore it is essential to avoid contact with battery acid.
- ▶ If clothing, skin or eyes have nevertheless come into contact with battery acid, immediately rinse the affected parts with water.
- ▶ If the eyes have been affected, immediately seek medical attention.
- ► Neutralise spilled battery acid immediately.

Check battery

Procedure

- Check the battery housing for cracks and any spilled acid. Remove any oxidisation remains from the battery terminals. Lubricate the battery terminals with an acid-free grease. Check the acid level.
- The acid should lie between the top and bottom markings.

Checking the acid density

Procedure

- Clean the area around the inspection plugs. If necessary, add distilled water to the top mark. Check the acid density.
- If the battery is charged sufficiently, the acid density should be 1.24 to 1.28 kg/l.
 - Recharge the battery if necessary. Fit the drain plug back on.

Battery disposal

Batteries may only be disposed of in accordance with national environmental protection regulations or disposal laws. The manufacturer's disposal instructions must be followed:

6.8 Exhaust system

Check the exhaust system regularly for leaks.

Procedure

- · Open the engine cover.
- Start the engine when the engine cover is open.
- Check for any rising smell of exhaust and altered engine noise level if you detect a rising smell of exhaust and altered engine noise level arrange for the exhaust system to be inspected by specialist personnel.

The exhaust system has now been checked for leaks.

NOTE

Check emissions at regular intervals

- ► Check the combustion engine exhaust emissions at regular intervals in accordance with national regulations.
- ▶ Black or blue exhaust smoke is an indicator of high emission levels resulting from combustion engine damage or wear.
- ▶ In this case the truck must be examined by specialist personnel.

6.9 Seat belt maintenance

Check the safety restraint belt

Procedure

- · Pull out the belt completely and check for fraying
- Test the belt buckle and make sure the belt returns correctly into the retractor.
- · Check the cover for damage.

Testing the automatic blocking system

Procedure

- Park the truck on a level surface.
- _ Pull out the seat belt with a jerk

The interlock must prevent the belt from coming out.

The seat belt service is now complete.

⚠ DANGER!

A faulty seat belt can cause injury

Using a faulty seat belt can result in injury.


- ▶ Only operate the truck with the seat belt intact. A faulty seat belt should be replaced immediately.
- ▶ The truck must remain decommissioned until a functional seat belt has been fitted.

6.10 Transmission

Check oil level

Procedure

- Open the engine cover.
- Remove the transmission oil dipstick (177)
- and wipe it off.
 Reinsert the transmission oil dipstick and pull it out. The oil level must be between the marks.
- Reinsert the transmission oil dipstick. Make sure it is closed correctly.



6.11 Brake

6.11.1 Checking the parking brake

The parking brake must be able to hold the truck plus the maximum load on an incline of 15%. If it cannot, the parking brake must be adjusted. Please contact Jungheinrich customer service in this case.

6.11.2 Checking the brake fluid level

Procedure

- Undo the screws of the left-hand panel.
- Remove the panel.
- · Check the brake fluid level on the brake fluid reservoir.
- The brake fluid level should lie between the MIN and MAX markings.
- If necessary, add brake fluid.
 - Capacity: 0.25 I
- · After adding brake fluid, refit the panel.

6.12 Restoring the truck to service after maintenance and repairs

Procedure

- Thoroughly clean the truck.
- Lubricate the truck according to the lubrication schedule, (see "Lubrication Schedule" on page 130).
- Clean the battery, grease the terminals and connect the battery.
- Check the transmission oil for condensation water and replace if necessary
- (hydrostatic trucks only).
 Check the hydraulic oil for condensation water and replace if necessary.
- The manufacturer's customer service department is specially trained to carry out these operations.

MARNING!

Faulty brakes can cause accidents

As soon as the truck has been started, test the brakes several times.

- ▶ Report any defects immediately to your supervisor.
- ► Tag out and decommission the faulty industrial truck.
- ▶Only return the truck to service when you have identified and rectified the fault.
- Start up the truck, (see "Preparing the Truck for Operation" on page 59).
- If there are switching problems in the electrical system, apply contact spray to the exposed contacts and remove any oxide layers on the contacts of the controls by applying them repeatedly.

7 **Decommissioning the industrial truck**

 \rightarrow

If the truck is to be out of service for more than a month, e.g. for commercial reasons, it must be stored in a frost-free and dry room. All necessary measures must be taken before, during and after decommissioning as described hereafter.

WARNING!

Lifting and jacking up the truck safely in order to raise the truck, the lifting gear must only be secured to the points specially provided for this purpose.

You may only work under a raised load handler / raised cab if they have been secured with a sufficiently strong chain or the fastening bolt.

In order to raise and jack up the truck safely, proceed as follows:

- ▶ Jack up the truck only on a level surface and prevent it from moving accidentally.
- Always use a jack with sufficient capacity. When jacking up the truck, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks).
- ▶In order to raise the truck, the lifting gear must only be secured to the points specially provided for this purpose, (see "Transport" on page 35).
- ► When jacking up the truck, take appropriate measures to prevent it from slipping or tipping over (e.g. wedges, wooden blocks).

When the truck is out of service it must be jacked up so that all the wheels are clear of the ground. This is the only way of ensuring that the wheels and wheel bearings are not damaged.

If the truck is to be out of service for more than 6 months, agree further measures with the manufacturer's customer service department.

7.1 Prior to decommissioning

Procedure

- Thoroughly clean the truck.
- · Test the brakes.
- Check the hydraulic oil level and replenish if necessary, (see "Checking the hydraulic oil level" on page 137).
- Apply a thin layer of oil or grease to any non-painted mechanical components.
- Lubricate the truck according to the lubrication schedule, (see "Lubrication Schedule" on page 130).
- Disconnect the battery, clean it and grease the terminals. In addition, follow the battery manufacturer's instructions.
 - Spray all exposed electrical contacts with a suitable contact spray.

7.2 During decommissioning

NOTE

Full discharge can damage the battery

Self-discharge can cause the battery to fully discharge. Full discharge shortens the useful life of the battery.

► Charge the battery at least every 2 months.

7.3 Restoring the truck to service after decommissioning

Procedure

- Thoroughly clean the truck.
- Lubricate the truck according to the lubrication schedule, (see "Lubrication Schedule" on page 130).
- Clean the battery, grease the terminals and connect the battery.
- Charge the battery, (see "Starter battery" on page 156).
- Check the transmission oil for condensation water and replace if necessary (hydrostatic trucks only).
- Check the engine oil for condensation water and replace if necessary.
- Check the hydraulic oil for condensation water and replace if necessary.
 The manufacturer's customer service department is specially trained to carry out these operations.

↑ WARNING!

Faulty brakes can cause accidents

As soon as the truck has been started, test the brakes several times.

- ▶ Report any defects immediately to your supervisor.
- ▶ Tag out and decommission the faulty industrial truck.
- ▶ Only return the truck to service when you have identified and rectified the fault.
- Start up the truck, (see "Preparing the Truck for Operation" on page 59).

 If there are switching problems in the electrical system, apply contact spray to the exposed contacts and remove any oxide layers on the contacts of the controls by applying them repeatedly.

8 Safety tests to be performed at intervals and after unusual incidents

Perform a safety check in accordance with national regulations. Jungheinrich recommends the truck be checked to FEM guideline 4.004. The Jungheinrich safety department has trained personnel who are able to carry out inspections.

The truck must be inspected at least annually or after any unusual event by a qualified

inspector (be sure to comply with national regulations). The inspector shall assess the condition of the truck from purely a safety viewpoint, without regard to operational or economic circumstances. The inspector shall be sufficiently instructed and experienced to be able to assess the condition of the truck and the effectiveness of the safety mechanisms based on the technical regulations and principles governing the inspection of forklift trucks.

A thorough test of the truck must be undertaken with regard to its technical condition from a safety aspect. The truck must also be examined for damage caused by possible improper use. A test report shall be provided. The test results must be kept for at least the next 2 inspections.

The owner is responsible for ensuring that faults are rectified immediately.

A test plate is attached to the truck as proof that it has passed the safety inspection.

This plate indicates the due date for the next inspection.

9 Final de-commissioning, disposal

Final de-commissioning or disposal of the truck in must be performed in accordance with the regulations of the country of use. In particular, regulations governing the disposal of batteries, fuels and electronic and electrical systems must be observed.

The truck must only be disassembled by trained personnel in accordance with the procedures as specified by the manufacturer. Note the manufacturer's safety instructions as specified in the service documentation.

10 Human vibration measurement

Vibrations that affect the driver during operation over the course of the day are known as human vibrations. Excessive human vibrations will cause the driver long term health problems. The European "2002/44/EC/Vibration" operator directive has therefore been established to protect drivers.

To help operators to assess the application situation, the manufacturer offers a service of measuring these human vibrations.

11 HUSS FS - MK Series Diesel Particle Filter Operating Instructions (O)

11.1 Important General Instructions

Read the operating instructions carefully before using the soot particle filter.

The general accident prevention and other health and safety regulations must be observed.

The use of additive-based fuels can have a negative effect on the exhaust and thus the useful life of the diesel particle filter. Therefore use only DIN EN 590 diesel with a Cetane rating above 50.

The HUSS diesel particle filter complies with TRGS 554, TA Air and VERT (Switzerland).

Application range of TRGS 554 (Technical Regulations for Hazardous Materials), TA Air and VERT:

- These Technical Regulations apply to work environments where diesel engine emissions may be contained in the air in the workplace.
- In Switzerland, VERT specifies in particular the requirements for tunnel building projects and major construction sites.

11.2 Important safety instructions

⚠ CAUTION!

The safe and proper use of the diesel particle filter requires careful operation and maintenance.

↑ CAUTION!

Operation and regeneration:

- ▶ The diesel particle filter may only be operated and regenerated by persons who have been trained in filter regeneration and are aware of the potential hazards.
- ▶ Only trained and authorized personnel may work on the diesel particle filter.
- ▶ Remove the diesel particle filter from service immediately if it is clearly damaged or not working properly. Avoid any build up of flammable materials near the filter.

⚠ DANGER!

Risk of burning!

During regeneration the entire diesel particle filter system heats up and hot exhaust emerges from the exhaust pipe.

Starting the truck in athazardousesituation (with starter interlock active):

166

• Depress and hold down both the "M" and "F" buttons on the HUSS control and at the same time start the industrial truck.

11.3 Functional Description

As the engine runs the diesel engine exhaust flows through the filter element which retains virtually all the harmful soot particles.

The longer the diesel engine runs, the more the diesel particle filter fills up and the greater the backpressure on the exhaust.

The level of the diesel particle filter is shown on the HUSS Control display, enabling regeneration to be made at the right time.

When a defined maximum backpressure or maximum charge time is reached, the HUSS Control activates the "Filter Full" alarm.


To burn off the soot particles in the filter element, the HUSS Control system starts regeneration when the engine is switched off.

A starter interlock and engine forced cutout are incorporated in the control system to protect the engine and diesel particle filter.

11.4 HUSS Control Operation

The diesel particle filter is operated by the HUSS Control unit. The control unit is mounted within the operator's field of vision.


The HUSS control system only works with the ignition is switched on.



Display

The top line shows the functional stages; in the bottom line a bar indicates the condition of the filter (backpressure / regeneration time)

Keys



11.5 HUSS Control Operating Instructions

Normal operation	Display	Function LED
Switch on the ignition. The buzzer sounds for min. 1 second and both LEDs light up at the same time.	Self test	Green and red LEDs lit
If a message is stored it will be displayed, in conjunction with the flashing red LED.	e.g. alarm / filter full HHHHHHHHHHHH	Red LED flashing
Stored message: Before the last cutout the exhaust backpressure exceeded the upper limit for at least 20 seconds or regeneration was interrupted. The buzzer sounds continuously.		
Note to this message: The industrial truck cannot be started, regeneration must be performed.	ATTENTION: in a hazardous situation the industrial truck can be started by continually pressing on the "M" and "F" buttons.	
If no message is stored the engine can be started.	Engine ready	

Messages in normal operation that indicate the status of the diesel particle filter:

with this message>>> Normal operation possible	Filter condition HHHHHHHH	Green LED flashing
with this message>>> Regeneration required	Regenerate HHHHHHHH	Red LED flashing
10 regenerations had to be made within the maximum charge time. Call the JH service department	Call service department / White ash	
Diesel particle filter maintenance required, the JH service department must be called.		Maintenance

11.6 Regeneration

Regenerate daily even if the filter is not full

Risk of fire and explosion

▶ Pay attention when handling fuel.

Avoid naked flames when handling fuel. Do not smoke. This applies even in areas where the fuel can only be smelled.

⚠ DANGER!

Risk of fire and poisoning

High temperatures and exhaust with poisonous content result every time combustion takes place.

The entire exhaust system becomes very hot during and immediately after operation.

Regeneration	Display
Park the truck on a level surface Switch off the engine. Ignition ON: HUSS Control is energised. Press the "M" button and hold it down for 5 seconds. Regeneration starts after 5 seconds.	Start regeneration in 5 sec. >>>>> Green LED
Other displays after the 5 seconds The fan is set to pre-cooling.	Pre-cooling glow plug
The glow plug is switched on.	Regeneration Start glow plug
The fuel-air mixture is ignited.	Regeneration Start ignition
The diesel particle filter is regenerated. The display shows the remaining regeneration time.	Regeneration on
Regeneration is complete. This display appears for 3 minutes.	Regeneration completed

Interrupting Regeneration	
Regeneration can be interrupted by switching off	"Filter full" alarm >>red LED
the ignition with the ignition key or by pressing the	flashes
"F" button on the control system. The display	
counts down from 5 seconds until the regeneration	
process is switched off. The buzzer sounds	
continuously.	/
IMPORTANT: If you press the "M" and "F" buttons	t om/

170

Interrupting Regeneration	
Faults	
All the hardware and software functions are tested	Glow plug fault
during regeneration.	Fuel pump fault
Any faults will cause the regeneration to be cancelled. Faults are displayed on the HUSS	Solenoid fault
control. The battery voltage is also checked. If the	Fan fault
minimum level is not reached, regeneration is cancelled. If one of the faults indicated here is displayed, call the JH service department to rectify	Temperature gauge fault
the fault.	Regeneration fault
	Regeneration interrupted Low voltage

11.7 Maintenance

The HUSS control displays the scheduled maintenance times.

Call the JH service department to carry out maintenance.

The Huss control system is factory-set for the industrial truck. Only trained JH service engineers are authorised to make changes to these settings.